


# User Manual



## NanoPro

### Control software for stepper motor controls and Plug & Drive motors (valid from version 1.7.0.0)

NANOTEC ELECTRONIC GmbH & Co. KG  
Kapellenstraße 6  
D-85622 Feldkirchen b. Munich, Germany

Tel. +49 (0)89-900 686-0  
Fax +49 (0)89-900 686-50  
[info@nanotec.com](mailto:info@nanotec.com)

## Editorial

© 2011

**Nanotec<sup>®</sup> Electronic GmbH & Co. KG**  
Kapellenstraße 6  
D-85622 Feldkirchen b. Munich, Germany

Tel.: +49 (0)89-900 686-0  
Fax: +49 (0)89-900 686-50

Internet: [www.nanotec.com](http://www.nanotec.com)

All rights reserved!

MS-Windows 2000/XP/Vista/7 are registered trademarks of the Microsoft Corporation.

### Translation of the original operation manual

#### Version/Change overview

Version	Date	Changes
1.0	06/03/2009	New issue C+P
2.0	10/01/2009	Revision of the new software release for version 1.52.09
2.1	11/05/2010	Revision of the new software release for version 1.60.0.0
2.2	11/03/2011	Revision of the new software release for version 1.7.0.0

## About this manual

### Target group

This user manual is aimed at designers and developers who need to configure one of the Nanotec<sup>®</sup> SMCI12, SMCI33, SMCI35, SMCI36, SMCI47-S-2, SMCP33 stepper motor controls or a Plug & Drive motor of the PDX-N series with the aid of the NanoPro control software without much experience of stepper motor technology.

### Important information

This manual only contains a description of the NanoPro control software, version 1.7.0.0 or later.




For the connection and the commissioning of stepper motor controls or Plug & Drive motors, see the respective technical manuals!

Nanotec<sup>®</sup> reserves the right to make technical alterations and further develop hardware and software in the interests of its customers to improve the function of this product without prior notice.

For criticisms, proposals and suggestions for improvement, please contact the above address or send an email to: [info@nanotec.com](mailto:info@nanotec.com)

### Additional manuals

Please also note the following manuals from Nanotec:

<b>Programming manual</b>	Controller programming <ul style="list-style-type: none"> <li>• Command Reference</li> <li>• NanoJ</li> <li>• COM interface</li> </ul>	
<b>NanoCAN User Manual</b>	Configuration of the CAN communication for CANopen-capable controllers with the NanoCAN software	
<b>Nanotec CANopen reference</b>	Detailed documentation of the CANopen functions	
<b>Technical manuals</b>	Connection and commissioning of stepper motor controls or Plug & Drive motors	

The manuals are available for download at [www.nanotec.com](http://www.nanotec.com).

## Contents

<b>1</b>	<b>Installation .....</b>	<b>6</b>
<b>2</b>	<b>Overview of the operating interface.....</b>	<b>7</b>
2.1	General information.....	7
2.2	Layout of operating interface .....	7
2.2.1	The menu bar.....	8
2.2.2	Menu window .....	10
<b>3</b>	<b>Controller configuration.....</b>	<b>11</b>
<b>4</b>	<b>&lt;Movement Mode&gt; Tab .....</b>	<b>12</b>
4.1	Overview .....	12
4.2	Entering profile parameters.....	14
4.3	Relative/absolute positioning, internal and external reference run.....	18
4.3.1	Description .....	18
4.3.2	Input and output assignments.....	19
4.3.3	Profile parameters.....	20
4.3.4	Signal curves.....	23
4.4	Speed mode.....	24
4.4.1	Description .....	24
4.4.2	Input and output assignments.....	25
4.4.3	Profile parameters.....	25
4.4.4	Signal curves in speed mode.....	26
4.5	Flag positioning mode.....	27
4.5.1	Description .....	27
4.5.2	Input and output assignments.....	28
4.5.3	Profile parameters.....	28
4.5.4	Signal curves in the Flag positioning mode .....	30
4.6	Clock Direction mode Int. Ref. / Ext. Ref. / Left / Right.....	31
4.6.1	Description .....	31
4.6.2	Input and output assignments.....	31
4.6.3	Profile parameters.....	32
4.6.4	Signal curves in the Clock Direction mode .....	33
4.7	Analog and Joystick mode .....	34
4.7.1	Description .....	34
4.7.2	Input and output assignments.....	34
4.7.3	Profile parameters.....	35
4.8	Analog positioning mode.....	36
4.8.1	Description .....	36
4.8.2	Input and output assignments.....	36
4.8.3	Profile parameters.....	37

---

4.9	Torque mode.....	38
<b>5</b>	<b>&lt;Motor Settings&gt; tab .....</b>	<b>39</b>
<b>6</b>	<b>&lt;Brake&gt; tab.....</b>	<b>43</b>
<b>7</b>	<b>&lt;Display Properties&gt; tab .....</b>	<b>45</b>
<b>8</b>	<b>&lt;Errorcorrection&gt; tab .....</b>	<b>46</b>
<b>9</b>	<b>&lt;Input&gt; tab.....</b>	<b>49</b>
<b>10</b>	<b>&lt;Output&gt; tab.....</b>	<b>56</b>
<b>11</b>	<b>&lt;Communication&gt; tab .....</b>	<b>58</b>
<b>12</b>	<b>&lt;Statusdisplay&gt; tab .....</b>	<b>60</b>
<b>13</b>	<b>&lt;CL-Parameter&gt; (Closed Loop) tab.....</b>	<b>62</b>
13.1.1	Configuring the Closed Loop current control .....	62
13.1.2	Velocity Loop.....	63
13.1.3	Position Loop .....	64
<b>14</b>	<b>&lt;Scope&gt; tab.....</b>	<b>74</b>
<b>15</b>	<b>&lt;Expert&gt; tab .....</b>	<b>77</b>
<b>16</b>	<b>Operating Several Motors .....</b>	<b>80</b>
<b>17</b>	<b>Troubleshooting.....</b>	<b>81</b>
17.1	General information.....	81
17.2	Error messages.....	82
Index.....		84

# 1 Installation

## System requirements

- MS-Windows 2000/XP/Vista/Windows 7
- Free COM port on your Windows PC

## Procedure

To install the NanoPro control software on your PC, you must first download the software from the Nanotec website.

To do this, proceed as follows:

Step	Action
1	Open the Nanotec website in your browser at <a href="http://www.nanotec.com">http://www.nanotec.com</a> .
2	Go to the "Downloads" area and select the following software: "Windows Software NanoPro for Plug & Drive & SMCI (NEW) >>"
3	Download the "NanoPro V xxx.zip" file onto your PC.
4	Unpack the zip file on your PC in the required directory.
5	Open the "NanoPro V xxx" folder and start the setup program by double-clicking on the "Setup_xxx.exe" file.
6	Follow the installation instructions of the setup program.

## 2 Overview of the operating interface

### 2.1 General information

#### Introduction

The SMCI12, SMCI33, SMCI35, SMCI36, SMCI47-S-2, SMCP33 stepper motor controls and Plug & Drive motors of the PDX-N series can be configured and programmed with the NanoPro control software using any standard Windows PC.

Transparent interfaces and simple test functions enable rapid entry into operation and programming and facilitate commissioning.

Due to the straightforward operating interface, not all functions are described in this manual. Much of it is self-explanatory. Therefore, only a few essential operational procedures are explained.

Familiarize yourself with the operating interface of the NanoPro control software before starting to commission and program the stepper motor controls or Plug & Drive motors.

### 2.2 Layout of operating interface

#### Menu bar and menu window


The operating interface is basically set up with a menu bar (1) and a separate menu window (2) for each motor.

The screenshot displays the NanoPro control software interface. At the top, a menu bar (1) includes 'File', 'Language', 'Motor 1', 'Motor', 'System', and 'Help'. Below the menu bar is a toolbar with buttons for 'Save Configuration to Drive' and 'Read Configuration from Drive'. A secondary menu bar (2) contains options: 'Movement Mode', 'Motor Settings', 'Brake', 'Display Properties', 'Errorcorrection', 'Input', 'Output', 'Communication', 'Statusdisplay', 'CL - Parameter', 'Scope', and 'Expert'. The main window is titled 'Drive Profile' and contains a list of 32 parameters on the left, with '01. Positionmode - Relative, 400, Left' selected. The central area features a configuration table with fields for 'Operation Type', 'Position Demand', 'Direction', 'Minimal Speed', 'Target Speed', 'Ramp', 'Brake Ramp', 'Break', 'Repetitions', 'Next Record', and 'Ramp Type'. To the right, a summary table lists 'Drive Speed', 'Acceleration', 'Acceleration Time', 'Step Mode', 'Phase Current', 'Gear Reduction', 'Output Speed', and 'Step Resolution'. Below the configuration fields are buttons for 'Test Record', 'Stop Record', 'Quick Stop', 'Save to Drive', and 'Read from Drive'. At the bottom, a graph shows a trapezoidal speed profile with a y-axis from 400 to 1000 Hz and an x-axis from 1 to 400 steps, with time markers at 2.08 ms and 402.16 ms.

## 2.2.1 The menu bar


### <File> menu

Standard functions for file editing.



### <Language> menu


The operating interface language can be changed here (German/English).



### "Motor" selection menu


Selection of the required motor.

In networks, up to 254 motors can be operated on a linked basis and actuated by the NanoPro control software.



### <Motor> menu

The <Motor> menu has the following menu items:




- <Add Motor>  
New motors can be added via the <Add Motor> menu item.  
An input window for the motor address opens. The address must be between 1 and 254.
- <Remove Motor>  
Motors that are no longer required can be removed from the controller in the <Remove Motor> menu item.  
This opens a window with the query "Do you really want to delete this motor?", which you can quit with the <Yes> button.
- <Copy Motor to>  
You can copy and adopt the current settings for a new motor with this menu item.  
An input window for the motor address opens. The address must be between 1 and 254.
- <Refresh all Motorvalues>  
All motor settings are transferred to the NanoPro control software.



- <Save all Motorvalues>  
All motor settings are saved in the controller.

### <System> menu


The <System> menu has the following menu items:



- <Firmware change>
  - <update to latest firmware>: Update the firmware in the controller to the latest firmware located in the firmware file for that controller.
  - <select firmware>: Select the firmware.
- <Firmwarefile update>  
Update of the firmware file (in the NanoPro installation directory) to a new firmware file from the Nanotec webserver.
- <Check for firmware update>  
Manually check whether an update for the firmware is available.
- <Firmware check automatic>  
When the checkbox is activated, an automatic check is made of whether a firmware update is available.
- <Show Expert Tab>  
When the checkbox is activated, the <Expert> tab is displayed in the tab bar.
- <Supportlog>  
When the checkbox is activated, a log file is automatically created for support purposes.

### <Help> menu

The <Help> menu has the following menu items:




- <Content>  
Call up the online help for NanoPro.
- <About NanoPro>  
Display the version information for the latest installation of NanoPro.

## 2.2.2 Menu window

### Tabs

The menu window contains the following tabs:



Tab	See section
Movement Mode	4 „<Movement Mode>“
Motor Settings	5 „<Motor Settings> tab“
Brake	6 „<Brake> tab“
Display Properties	7 „<Display Properties> tab“
Errorcorrection	8 „<Errorcorrection> tab“
Input	9 „<Input> tab“
Output	10 „<Output> tab“
Communication	11 „<Communication> tab“
Statusdisplay	12 „<Statusdisplay> tab“
CL Parameter	13 „<CL-Parameter> (Closed Loop) tab“
Scope	14 „<Scope> tab“
Expert (display must be activated via the <System → Show Expert Tab> menu)	15 „<Expert> tab“

### Transferring settings to/from controller

The current configuration settings can be saved in the connected controller or read from the connected controller using the following buttons.



- <Save Configuration to Drive>  
 The current settings are transferred from the NanoPro to the connected controller.
- <Read Configuration from Drive>  
 The current settings are transferred from the connected controller to NanoPro.

## 3 Controller configuration

### General information

This Section describes the general procedure for configuring the controller. The parameters to be configured on the respective tabs are described in detail in sections 4 to 15.

### Procedure

To configure the drivers, proceed as follows:

Step	Action	Note
1	Commission the controller and establish communication with the controller.	See technical manual of the respective controller.
2	Click on the <Read Configuration from Drive> button. The connected controller type is detected and displayed in the <Motor settings> tab. The parameters applicable for the respective controller type are displayed.	See Section 5 “<Motor Settings> tab”
3	If this is not a Plug & Drive motor: Select the motor type and motor designation (see motor type plate) in the <Motor settings> tab. Motor type and designation are detected automatically for Plug & Drive motors.	See Section 5 “<Motor Settings> tab”
4	Enter the required parameters in the tabs and click, if necessary, on the <Save Data> button to transfer the settings of the respective tab to the controller.	See Section 4.2 „Entering profile parameters“, for example.
5	Click on the <Save Configuration to Drive> button, if necessary, to transfer all settings from NanoPro to the controller.	

## 4 <Movement Mode> Tab

### 4.1 Overview

#### Introduction

Depending on the travel profile, the motor can be operated using a total of 14 different operating modes; see also Section 4.2 „Entering profile parameters“. Due to the great capacity of functions available, it offers designers and developers a rapid and simple method of resolving numerous drive requirements with less programming effort.

Select the required operating mode for each travel profile and configure the controller according to your requirements.

#### Overview of operating modes and their areas of application

Operating mode	Application
Positionmode - Relative	Use this mode if you would like to travel to a specific position. The motor travels according to a specified travel profile from a Position A to a Position B. Please refer to Section 4.3 "Relative/absolute positioning, internal and external reference run".
Positionmode - Absolute	
Internal reference run	During the internal reference run, the motor travels to an internal reference point at the set minimum speed. Please refer to Section 4.3 "Relative/absolute positioning, internal and external reference run".
External reference run	During an external reference run, the motor travels to a switch connected to the reference input. Please refer to Section 4.3 "Relative/absolute positioning, internal and external reference run".
Speed mode	Use this mode when you wish to travel with a specific speed (e.g. a conveyor belt or pump speed). In the speed mode, the motor accelerates with a specified ramp from the starting speed (start frequency "V Start") to the specified maximum speed (maximum frequency "V Normal"). With multiple inputs, the rotational speed can be controlled at various speeds on-the-fly. Please refer to Section 4.4 "Speed mode".
Flag positioning mode	The flag positioning mode offers a combination of the speed and positioning modes. The motor is initially operated in speed mode; when a trigger point is reached, it changes to the positioning mode and the specified setpoint position (relative to the trigger position) is approached. This operating mode is used for labeling, for example: the motor first travels with the set ramp to the synchronous speed of the conveyed goods. When the labels are detected, the preset distance (position) is traveled to apply the labels. Please refer to Section 4.5 "Flag positioning mode".

Operating mode	Application
Clock Direction mode, left	Use this mode when you wish to operate the motor with a superordinate controller (e.g. CNC controller). In the clock direction mode, the motor is operated via two inputs with a clock and a direction signal from a superordinated positioning controller (indexer). Depending on the mode selected (Int. Ref./Ext. Ref.), the internal and external reference runs are supported. Please refer to Section 4.6 "Clock Direction mode Int. Ref. / Ext. Ref.".
Clock Direction mode, right	
Clock direction mode Int. Ref.	
Clock direction mode Ext. Ref.	
Analog and Joystick mode	The motor is actuated in this operating mode simply with a potentiometer or a Joystick (–10 V to +10 V). Use this mode if you want to use the motor in a simple application: <ul style="list-style-type: none"> <li>• Setting a specific speed, e.g. via an external potentiometer,</li> <li>• Traveling synchronously with a superordinate controller with analog output (–10 V to +10 V).</li> </ul> Please refer to Section 4.7 "Analog and Joystick mode".
Analog Positioning mode	Use this mode if you would like to travel to a specific position. The voltage level at the analog input is proportionate to the desired position, thus enabling servo performance. Please refer to Section 4.8 "Analog positioning mode".
Torque mode	Use this mode if you would like to have a certain output torque independent of the rotational speed, as is typically the case with winding and unwinding applications. The maximum torque is specified via the analog input. Please refer to Section. 4.9 „Torque mode“

## 4.2 Entering profile parameters

### Introduction

Up to 32 travel profiles can be defined and programmed.

You can assign important profile parameters to a travel profile using the NanoPro software.

The parameters listed below do not all have to be specified for all travel modes. When the operation mode is activated or changed, the relevant fields are displayed in the <Movement Mode> tab.

### <Movement Mode> tab

The profile parameters for a specific travel profile are set on the <Movement Mode> tab.

The screenshot displays the NanoPro software interface for configuring a travel profile. The main window is titled "Movement Mode" and contains several tabs: Motor Settings, Brake, Display Properties, Errorcorrection, Input, Output, Communication, Statusdisplay, CL - Parameter, Scope, and Expert. The "Drive Profile" list on the left shows 32 profiles, with "01. Positionmode - Relative, 400, Left" selected. The main configuration area includes the following parameters:


- Operation Type: Positionmode - Relative
- Position Demand: 400 (Steps)
- Direction: Left
- Minimal Speed: 400 (Hz)
- Target Speed: 1000 (Hz)
- Ramp: 288.3 (Hz/ms)
- Brake Ramp: 288.3 (Hz/ms)
- Break: 1 (ms)
- Repetitions: 1
- Next Record: Number Type
- Ramp Type: Trapezoid Ramp

A summary table on the right provides the following values:

Drive Speed	400 Hz
Acceleration	288.3 Hz/ms
Acceleration Time	2.08 ms
Step Mode	Half Step
Phase Current	10%
Gear Reduction	1:1
Output Speed	400 Hz
Step Resolution	1.8°

At the bottom, a graph shows the frequency profile. The y-axis is labeled "1000 [Hz]" and "400 [Hz]". The x-axis is labeled "400 [Steps]" and "402.16 [ms]". The graph shows a trapezoidal ramp profile starting at 400 Hz, ramping up to 1000 Hz at 2.08 ms, holding at 1000 Hz until 399 steps, and then ramping down to 400 Hz at 402.16 ms.

### Drive Profile selection list




- This window displays the maximum possible 32 travel profiles.
- After selecting the required travel profile, the corresponding profile parameters are displayed in the parameter area .

### “Operation Type” selection menu


- The required operating type can be selected here.

### Profile parameters



- Displays parameters dependent on the selected operating type and travel profile.
- Settings of required parameters for the various profiles (max. 32).

### Motor parameters




- Display of the parameters of the connected motor.
- Setting of parameters, see 5 "<Motor Settings> tab".

### Buttons for communication with the controller




- <Test Record>  
Activation of the <Test Record> button transmits the current record to the controller and starts it. The parameters are not stored by the controller.
- <Stop record>  
The currently operating record is stopped.
- <Quick Stop>  
The currently operating record is stopped – independent of the travel profile – with the Quick Stop ramp. For the settings, see Section 5 "<Motor Settings> tab".
- <Save Data>  
Pressing the <Save Data> button permanently stores the set travel profile in the controller.  
Transfer can take a few seconds and is visually displayed with a progress bar.  
The travel profiles can then be selected and started via the motor inputs.
- <Read from Drive>  
All record data stored in the controller is loaded onto your PC.

### Display profile graph



- The displayed profile graph can be used to rapidly see the ramp times (acceleration time) and the overall actuating time for the applicable travel profile.
- The graphic is recalculated after every relevant input.

### Buttons for motor position/communication with the optional encoder



- <Query State>  
Pressing the <Query State> button queries the actual state of the motor and displays the state on the screen.
- <Reset counter>  
Pressing the <Reset counter> button resets the current counter value to zero.



- <Read Counter>  
Pressing the <Read Counter> button queries the actual counter value and displays it on screen.
- <Delivery Status>  
Pressing the <Delivery Status> button resets all parameter settings in the controller to the default condition.

### Procedure

The following describes an example of how to enter profile parameters for a travel profile in the "Relative" operation type. Other parameters must be defined in other operating modes.

Proceed as follows:

Step	Action	Note
1	Select the required travel profile in the <Movement Mode> tab, e.g. "01. Relative, 400,-".	The parameter values of the selected travel profile are displayed. The travel profile is defined by the positioning mode ("Operation Type" selection menu) and the distances in the field "Position Demand".
2	In the "Operation Type" selection menu, select the "Relative" mode.	The relevant parameter fields are displayed.
3	Enter the desired parameters.	See Section 4.3.3 "Profile parameters".
4	If you want to test the entered travel profile: Click on the <Test Record> button.	The motor then travels according to the selected operating mode and travel profile.
5	Repeat steps 1 to 4 if you want to enter further travel profiles.	
6	If you want to permanently save the entered settings: Click on the <Save to Drive> button.	The data are then saved in the controller.

## 4.3 Relative/absolute positioning, internal and external reference run

### 4.3.1 Description

#### Function

##### Relative and absolute positioning

In the "Relative" and "Absolute" operation types, the motor moves from a position A to a position B according to a specified travel profile.

They are preferentially used when travel to a specific position is required.

The positions can be defined as absolute or relative values depending on the mode selected. With relative positioning the travel profile is started from the actual position. With absolute positioning, the travel profile starts from a specified zero position, irrespective of the actual position.

##### Internal and external reference run

In the "Internal reference run" operation type, the motor travels to an internal reference point at the set minimum speed (index mark of encoder).

In the "External reference run" operation type the motor travels to a switch connected to the reference input.

After the start of the external reference run, the motor accelerates with the set ramp from the minimum to the maximum speed. Once the reference switch is reached, movement is stopped for a break of 100 ms and then, according to the "Limit switch behavior internal/external" setting (see Section 9 "<Input>", "Behavior for Internal / External"), travel is recommenced away from the switch at the minimum speed (start/stop speed).

The reference switch can be an opener or a closer. This must be set with the software during programming.

See also Section 9 "<Input> tab" and the separate manual for the respective stepper motor control or for the Plug & Drive motor.

#### Parameter fields for the "Relative" operation type

Operation Type	Positionmode - Relative	
Position Demand	400	Steps
Direction	Left	
Minimal Speed	400	Hz
Target Speed	1000	Hz
Ramp	288.3	Hz/ms
Brake Ramp	288.3	Hz/ms
Break	1	ms
Repetitions	1	
	<input type="checkbox"/> Reverse Direction	
Next Record	Number Type	
Ramp Type	Sinus Ramp	

### Parameter fields with the “Absolute” operation type

Operation Type	Positionmode - Absolute	
Position Demand	400	Steps
Target Speed	1000	Hz
Ramp	288.3	Hz/ms
Brake Ramp	288.3	Hz/ms
Next Record	Number Type	
Ramp Type	Sinus Ramp	

### Parameter fields with the "Reference Run Internal" operation type

Operation Type	Reference Run Internal	
Direction	Left	
Target Speed	1000	Hz
Ramp	288.3	Hz/ms
Brake Ramp	288.3	Hz/ms
Break	1	ms
Repetitions	1	
Next Record	Number Type	
Ramp Type	Sinus Ramp	

### Parameter fields with the "Reference Run External" operation type

Operation Type	Reference Run External	
Direction	Left	
Target Speed	1000	Hz
Ramp	288.3	Hz/ms
Brake Ramp	288.3	Hz/ms
Break	1	ms
Repetitions	1	
Next Record	Number Type	
Ramp Type	Sinus Ramp	

## 4.3.2 Input and output assignments

### General information

The inputs and outputs are freely configurable, see Section 9 "<Input> tab and Section 10 "<Output> tab".

### Possible input configuration

The inputs can be configured with the following functions:


- Start/reset
- Record bit 0 to record bit 4
- External reference switch


### 4.3.3 Profile parameters

#### Parameter descriptions

The following parameters can be set:

Parameter	Function
Position Demand	<ul style="list-style-type: none"> <li>• Absolute or relative position for the selected travel profile (distance).</li> <li>• The control variable can be input in steps, degrees or mm.</li> <li>• The units of measurement can be changed in the &lt;Display Properties&gt; tab.</li> </ul>
Direction (not with absolute positioning)	Direction of rotation of travel profile <ul style="list-style-type: none"> <li>• Left</li> <li>• Right</li> </ul>
Minimal Speed	"Start speed" (V Start): <ul style="list-style-type: none"> <li>• Start speed (start/stop frequency) of the motor in Hz.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a minimum speed can also lead to step losses.</li> <li>• The units of measurement can be changed in the &lt;Display Properties&gt; tab.</li> </ul>
Target Speed	"Normal speed" (V Normal): <ul style="list-style-type: none"> <li>• Normal travel speed of the motor in Hz.</li> <li>• To avoid step losses, it should lie outside the resonance ranges.</li> <li>• Too high a maximum speed can cause step losses and motor stalling.</li> <li>• The units of measurement can be changed in the &lt;Display Properties&gt; tab.</li> </ul>
Ramp / Brake Ramp	Ramp gradient: <ul style="list-style-type: none"> <li>• Values are entered in Hz/ms.</li> <li>• The steeper the ramp, the faster the acceleration; however, if the acceleration is too high, the motor can skip and lose steps.</li> <li>• Any possible resonance ranges must be traversed as fast as possible.</li> <li>• The maximum value is 3000 Hz/ms. The set value is output as the next possible speed due to the coding in the motor (at 3000 Hz/ms e.g. as 2988.3 Hz/ms).</li> <li>• The minimum value is 0.1 Hz/ms.</li> <li>• Brake ramp: The value 0 means that the value set in the "Ramp" field for the acceleration ramp is also applied for the brake ramp.</li> </ul>
Break (only with relative positioning)	<ul style="list-style-type: none"> <li>• The idle time of the motor (in ms) when several runs must be implemented in sequence.</li> <li>• The minimum duration of the adjustable break is 1 ms.</li> </ul>


Parameter	Function
Repetitions (only with relative positioning)	The "Repetitions" parameter indicates how often the selected travel profile should be implemented automatically in sequence without another start command. A value of 0 means that the selected travel profile is traveled an infinite number of consecutive times.
Reverse direction (only with relative positioning)	<ul style="list-style-type: none"> <li>• An automatic change of direction can be activated in the "Reverse Direction" option field.</li> <li>• In active change of direction, the rotation direction of the motor is automatically changed when the same record is called up repeatedly in sequence.</li> </ul>
Next Record	A travel profile can be defined in this selection menu to be started when the current record is ended.
Ramp Type	<p>The following ramp types can be selected:</p> <ul style="list-style-type: none"> <li>• Trapezoid ramp</li> <li>• Sinus ramp</li> <li>• Jerk Free Ramp</li> </ul> <p>The following additional parameter fields appear if the "Jerk Free Ramp" has been selected:</p>  <p>Possible values: 1 to 65,536</p> <p>The "Max. Acceleration Jerk" and "Max. Brake Jerk" parameters indicate the maximum change of acceleration over time. The greater the jerk, the faster the acceleration can change. A very small jerk leads to a sinusoidal acceleration ramp while a large jerk leads to a trapezoidal ramp, see following figure:</p>

Parameter	Function
Ramp Type (continued)	 <p>The figure contains two graphs illustrating speed profiles over time. The top graph, labeled 'Minor jolt', shows a speed profile that starts at zero and increases with a curve that becomes steeper as it approaches a maximum speed. An arrow points to the point where the curve becomes a straight line, labeled 'Max. acceleration reached'. The bottom graph, labeled 'Major jolt', shows a speed profile that starts at zero and increases linearly to a maximum speed. An arrow points to the start of this linear increase, labeled 'Max. acceleration reached'.</p>

### Profile graph display

The displayed profile graph shows the ramp times (acceleration time) and the overall actuating time for the applicable travel profile.


The graphic is recalculated after every relevant input. This allows you to continually check and, where necessary, correct the settings made.



### 4.3.4 Signal curves

#### Example of a signal curve

In this example, travel profile 5, then travel profile 3, followed by travel profile 16 (programmed as reference run) are started.



## 4.4 Speed mode

### 4.4.1 Description

#### Function

In the speed mode, the motor accelerates with a specified ramp from the starting speed (minimal speed/start frequency) to the specified maximum speed (target speed/maximum frequency).

The speed mode is generally used when a specific travel speed is required (e.g. for a conveyor belt or a pump).

#### Parameter fields for “Speed” operation type

Operation Type	Speed	
Direction	Left	
Minimal Speed	400	Hz
Target Speed	1000	Hz
Ramp	10	Hz/ms
Brake Ramp	0	Hz/ms
Ramp Type	Trapezoid Ramp	

#### Speed changes

Speed changes can be implemented at any time via the inputs or the interface. Unlike the other operation modes, the state of the inputs is read in during travel and the associated speed parameters are output. When the speed changes, the motor accelerates or brakes with the set ramp to the new setpoint speed.

If you start the motor for test purposes via the NanoPro controller software (click on <Test Record> button), the following buttons change:

Test Record
Stop Record
Quick Stopp
increase frequency
decrease frequency

- The <Save to Drive> button changes to the <increase frequency> button: Clicking on the button increases the frequency (speed) of the motor by 100 Hz. The current frequency value is shown in the window at the top right ("Drive Speed").
- The <Read from Drive> button changes to the <decrease frequency> button: Clicking on the button decreases the frequency (speed) of the motor by 100 Hz. The current frequency value is shown in the window at the top right ("Drive Speed").



## 4.4.2 Input and output assignments

### General information

The inputs and outputs are freely configurable; see Section 9 "<Input>" and Section 10 "<Output>".

### Possible input configuration

The inputs can be configured with the following functions:

- Start/reset
- Record bit 0 to record bit 4
- Direction (direction of rotation of motor)

## 4.4.3 Profile parameters

### Parameter descriptions


The following parameters can be set in the speed mode:

Parameter	Function
Direction	Direction of rotation of travel profile: <ul style="list-style-type: none"> <li>• Left</li> <li>• Right</li> </ul> The direction of rotation of the motor is only relevant when the motor is operated via the programming interface. Otherwise, the direction of rotation is selected via an input.
Minimal speed	"Starting speed" <ul style="list-style-type: none"> <li>• The minimum speed in Hz is the startup speed (start-stop frequency) of the motor.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a minimum speed can also lead to step losses.</li> </ul>
Target speed	"Normal speed": <ul style="list-style-type: none"> <li>• The maximum speed in Hz is the setpoint speed of the motor.</li> <li>• To avoid rough operation, it should lie outside resonance ranges.</li> <li>• Too high a maximum speed can cause step losses and motor stalling.</li> </ul>
Ramp / Brake Ramp	Input of ramp gradient in Hz/ms. Brake ramp: The value 0 means that the value set in the "Ramp" field for the acceleration ramp is also applied for the brake ramp.
Ramp Type	The following ramp types can be selected: <ul style="list-style-type: none"> <li>• Trapezoid ramp</li> <li>• Sinus ramp</li> <li>• Jerk Free Ramp (see Section 4.3.3)</li> </ul>

### Profile graph display

The displayed profile graph shows the ramp times (acceleration time) and the setpoint speed for the applicable travel profile.


The graphic is recalculated after every relevant input. This allows you to continually check and, where necessary, correct the settings made.



### 4.4.4 Signal curves in speed mode

#### Example of a signal curve

In the example, speeds of travel profile 4, travel profile 7 and, after a change of direction, the speed of travel profile 13 are used.




## 4.5 Flag positioning mode

### 4.5.1 Description

#### Function

The flag positioning mode offers a combination of the speed and positioning modes. The motor is first operated in speed mode to travel an undefined distance with a specific speed, for example. When a trigger (trigger point) is reached, e.g. a limit switch, operation is switched to the relative positioning mode to travel to a defined setpoint position (relative to the trigger position).



#### Parameter fields in the “Flag Position” operation type

Operation Type	Flag Position	
Position Demand	400	Steps
Direction	Left	
Target Speed	1000	Hz
V Maximum	25000	Hz
Ramp	288.3	Hz/ms
Brake Ramp	288.3	Hz/ms
Break	1	ms
Repetitions	1	
Next Record	Number Type	
Ramp Type	Sinus Ramp	

### Manually setting the trigger signal

The trigger signal can be set manually at input 5 via the NanoPro controller software.

If you start the motor for test purposes (click on the <Test Record> button), the following button changes:



- The <Test Record> button changes to the <Trigger on> button: When this button is clicked, the trigger signal is set and the motor changes from the Speed mode to the Relative positioning mode.

## 4.5.2 Input and output assignments

### General information

The inputs and outputs are freely configurable, see Section 9 "<Input> tab" and Section 10 "<Output> tab".

### Possible input configuration

The inputs can be configured with the following functions:

- Start/reset (starts the speed mode)
- Record bit 0 to record bit 4
- Trigger (starts the positioning mode)
- External reference switch

## 4.5.3 Profile parameters

### Parameter descriptions

The following parameters can be set in the flag positioning mode:


Parameter	Function
Position Demand	<ul style="list-style-type: none"><li>• Distance for the selected travel profile.</li><li>• The number of motor steps to be output can be selected up to 16,777,215 steps.</li></ul>
Direction	Direction of rotation of travel profile: <ul style="list-style-type: none"><li>• Left</li><li>• Right</li></ul>

Parameter	Function
Minimal Speed	"Starting speed" <ul style="list-style-type: none"> <li>• The minimum speed in Hz is the startup speed (start-stop frequency) of the motor.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a minimum speed can also lead to step losses.</li> </ul>
Target Speed	"Maximum speed 1": <ul style="list-style-type: none"> <li>• The maximum speed <u>before</u> the trigger pulse (speed mode) in Hz.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a maximum speed can cause step losses and motor stalling.</li> </ul>
V Maximum	"Maximum speed 2": <ul style="list-style-type: none"> <li>• The maximum speed <u>after</u> the trigger pulse (positioning mode) in Hz.</li> <li>• Default set to 1000 Hz.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a maximum speed can cause step losses and motor stalling.</li> </ul>
Ramp / Brake Ramp	Input of ramp gradient in Hz/ms. Brake ramp: The value 0 means that the value set in the "Ramp" field for the acceleration ramp is also applied for the brake ramp.
Break	<ul style="list-style-type: none"> <li>• The idle time of the motor (in ms) when several runs must be implemented in sequence.</li> <li>• The minimum duration of the adjustable break is 1 ms.</li> </ul>
Repetitions	The "Repetitions" parameter indicates how often the selected travel profile should be implemented automatically in sequence without another start command.
Next Record	A travel profile can be defined in this selection menu to be called up when the current record is ended.
Ramp Type	The following ramp types can be selected: <ul style="list-style-type: none"> <li>• Trapezoid ramp</li> <li>• Sinus ramp</li> <li>• Jerk Free Ramp (see Section 4.3.3)</li> </ul>

### Profile graph display


The displayed profile graph shows the ramp times (acceleration time) and the overall actuating time for the applicable travel profile.

The graphic is recalculated after every relevant input. This allows you to continually check and, where necessary, correct the settings made.



### 4.5.4 Signal curves in the Flag positioning mode

In this example, travel profile 4 is started and then a reference run (programmed as travel profile 8) is started.



## 4.6 Clock Direction mode Int. Ref. / Ext. Ref. / Left / Right

### 4.6.1 Description

#### Function

In the Clock Direction modes, the motor is operated via two inputs with a clock and a direction signal from a superordinated positioning control (indexer).

With the Clock Direction Left/Right modes, the motor can be moved manually into the selected rotation direction. With every clock signal, the motor moves one step in the direction set by the direction signal. The motor can be started by clicking on the <Test Record> button.

In the Clock Direction modes Int. Ref. / Ext. Ref., the internal or, respectively, external reference runs are supported (see Section 9 "<Input> tab" and the separate manual for the respective stepper motor control or for the Plug & Drive motor).

#### Parameter fields in the "Clock Direction Left/Right" operation type

Operation Type	<input type="text" value="Clock Direction Left"/>	
Target Speed	<input type="text" value="1000"/>	Hz
Ramp	<input type="text" value="288.3"/>	Hz/ms
Brake Ramp	<input type="text" value="288.3"/>	Hz/ms
Ramp Type	<input type="text" value="Sinus Ramp"/>	

#### Parameter fields in the "Clock Direction Run Int. Ref. / Ext. Ref." operation type

Operation Type	<input type="text" value="Clock Direction Run Int. Ref."/>	
Direction	<input type="text" value="Left"/>	
Target Speed	<input type="text" value="1000"/>	Hz
Ramp	<input type="text" value="288.3"/>	Hz/ms
Brake Ramp	<input type="text" value="288.3"/>	Hz/ms
Ramp Type	<input type="text" value="Sinus Ramp"/>	

### 4.6.2 Input and output assignments

#### General information

The inputs and outputs are freely configurable, see Section 9 "<Input> tab" and Section 10 "<Output> tab".

#### Possible input configuration

The inputs can be configured with the following functions:

- Start/reset
- Clock Direction mode, mode selection 1
- Clock Direction mode, mode selection 2
- External reference switch
- Direction (direction of rotation of the motor):  
A signal change at this input must be completed at least 150 µs before a clock signal.
- Clock

### 4.6.3 Profile parameters

#### Parameter descriptions

The following parameters can be set in the clock direction mode:

Parameter	Function
Direction	Direction of rotation of travel profile: <ul style="list-style-type: none"><li>• Left</li><li>• Right</li></ul>
Minimal Speed	"Starting speed" <ul style="list-style-type: none"><li>• The minimum speed in Hz is the startup speed (start-stop frequency) of the motor.</li><li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li><li>• Too high a minimum speed can also lead to step losses.</li></ul>
Target Speed (only active if there is no external frequency)	"Normal speed": <ul style="list-style-type: none"><li>• The maximum speed in Hz is the setpoint speed of the motor.</li><li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li><li>• Too high a maximum speed can cause step losses and motor stalling.</li></ul>
Ramp / Brake Ramp	Input of ramp gradient in Hz/ms. Brake ramp: The value 0 means that the value set in the "Ramp" field for the acceleration ramp is also applied for the brake ramp.


**Note:**

For controllers with a dspDrive, when using the clock direction mode in 1/32 or 1/64 step mode, the scaling factors P and I should be set to 0 in the PI parameters of the dspDrive since resonances may otherwise occur at high speeds.



#### 4.6.4 Signal curves in the Clock Direction mode

In this example, the left and right modes are started after one another and then the external reference run is carried out.



## 4.7 Analog and Joystick mode

**Note:**

The analog and joystick modes differ only in a few details. Both modes are therefore described here in one section.

### 4.7.1 Description

#### Function

In the analog or joystick mode, a stepper motor is operated in a simple application:

- with a specific speed, e.g. via an external potentiometer,
- or synchronously with a superordinate controller with analog output (–10 V to +10 V).

The motor is simply actuated either by a potentiometer or an external power supply and a joystick (maximum –10 V to +10 V).

The motor operates at a speed proportional to the applied voltage. The voltage is resolved with an accuracy of 10 bits. The smaller the selected voltage range is, the worse the resolution of the speed will be. To define the voltage range, see Section 9 "<Input> tab".

#### Parameter fields in the “Analog” operation mode

Operation Type	<input type="text" value="Analogue"/>	
Direction	<input type="text" value="Left"/>	
Target Speed	<input type="text" value="1000"/>	Hz
Ramp	<input type="text" value="288.3"/>	Hz/ms
Brake Ramp	<input type="text" value="288.3"/>	Hz/ms
Ramp Type	<input type="text" value="Sinus Ramp"/>	

#### Parameter fields in the “Joystick” operation mode

Operation Type	<input type="text" value="Joystick"/>	
Target Speed	<input type="text" value="1000"/>	Hz
Ramp	<input type="text" value="288.3"/>	Hz/ms
Brake Ramp	<input type="text" value="288.3"/>	Hz/ms
Ramp Type	<input type="text" value="Sinus Ramp"/>	

### 4.7.2 Input and output assignments

#### General information

The inputs and outputs are freely configurable, see Section 9 "<Input> tab" and Section 10 "<Output> tab".

#### Possible input configuration

The inputs (digital) can be configured with the following functions, for example:

- Start/reset
- Record bit 0 to record bit 4
- Direction

### 4.7.3 Profile parameters

#### Parameter descriptions

The following parameters can be set in the analog or joystick mode:

Parameter	Function
Direction (only in Analogue mode)	Direction of rotation of travel profile: <ul style="list-style-type: none"> <li>• Left</li> <li>• Right</li> </ul> The direction setting is only significant if no input is configured for direction, since this input would in this case have higher priority. <p><b>Note:</b> In Joystick mode, the voltage sign determines the direction of rotation (– means "rotate left", + means "rotate right").</p>
Minimal Speed	"Starting speed" <ul style="list-style-type: none"> <li>• The minimum speed in Hz is the startup speed (start-stop frequency) of the motor.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a minimum speed can also lead to step losses.</li> </ul>
Target Speed	"Normal speed": <ul style="list-style-type: none"> <li>• The maximum speed in Hz is the setpoint speed of the motor.</li> <li>• To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>• Too high a maximum speed can cause step losses and motor stalling.</li> </ul>
Ramp	Input of ramp gradient in Hz/ms. In the analog and joystick modes, the ramp determines the maximum acceleration. If the voltage changes too fast, e.g. by turning the potentiometer too rapidly, this ramp is used to accelerate to the maximum rotational speed.
Brake Ramp	Input of ramp gradient in Hz/ms. In the analog and joystick modes, the brake ramp determines the maximum deceleration. If the voltage changes too fast, e.g. by turning the potentiometer too rapidly, this ramp is used to decelerate to a standstill. The value 0 means that the value set for the acceleration ramp can also be used for the brake ramp.

## 4.8 Analog positioning mode

### 4.8.1 Description

#### Function

A specific position can be approached in this mode.

The analog input can be actuated with max.  $-10\text{ V}$  to  $+10\text{ V}$ . The voltage at the analog input directly controls the position. To define the voltage range, see Section 9 "<Input> tab".

#### Parameter fields

Operation Type	<input type="text" value="Analogue Position"/>	
Position Demand	<input type="text" value="400"/>	Steps
Target Speed	<input type="text" value="1000"/>	Hz
Ramp	<input type="text" value="288.3"/>	Hz/ms
Brake Ramp	<input type="text" value="288.3"/>	Hz/ms
Ramp Type	<input type="text" value="Sinus Ramp"/>	

### 4.8.2 Input and output assignments

#### General information

The inputs and outputs are freely configurable, see Section 9 "<Input> tab" and Section 10 "<Output> tab".

#### Possible input configuration

The inputs (digital) can be configured with the following functions, for example:

- Start/reset
- Record bit 0 to record bit 4

### 4.8.3 Profile parameters


#### Parameter descriptions

The following parameters can be set in the analog positioning mode:

Parameter	Function
Position Demand	<ul style="list-style-type: none"> <li>Distance for the selected travel profile.</li> <li>The number of motor steps to be output can be selected up to 16,777,215 steps.</li> </ul>
Minimal Speed	<p>"Starting speed"</p> <ul style="list-style-type: none"> <li>The minimum speed in Hz is the startup speed (start-stop frequency) of the motor.</li> <li>To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>Too high a minimum speed can also lead to step losses.</li> </ul>
Target Speed	<p>"Normal speed":</p> <ul style="list-style-type: none"> <li>The maximum speed in Hz is the setpoint speed of the motor.</li> <li>To avoid step losses, it should be selected to be above the natural resonance of the motor.</li> <li>Too high a maximum speed can cause step losses and motor stalling.</li> </ul>
Ramp	<p>Input of ramp gradient in Hz/ms.</p> <p>In the analog positioning mode, the ramp determines the maximum acceleration.</p> <p>If the voltage changes too fast, e.g. by turning the potentiometer too rapidly, this ramp is used to accelerate to the maximum rotational speed.</p>
Brake Ramp	<p>Input of ramp gradient in Hz/ms.</p> <p>In the analog positioning mode, the brake ramp determines the maximum deceleration.</p> <p>If the voltage changes too fast, e.g. by turning the potentiometer too rapidly, this ramp is used to decelerate to a standstill.</p> <p>The value 0 means that the value set for the acceleration ramp can also be used for the brake ramp.</p>

## 4.9 Torque mode

### Display



### Function

The torque mode is used to rotate the motor at a constant torque.

The torque is determined by the analog input (see configuration of analog input in <Input> tab). The maximum current is limited by the set phase current (see "Phase current" parameter in the <Motor Settings> tab).

The rotational speed is not fixed in this mode: the greater the load on the motor, the lower the rotational speed. The speed that is set depends on the type of motor used and the current setting.

Ramps are not used in the Torque mode. The rate at which the motor accelerates only depends on the setting for current.

**Note:**

The Torque mode can only be used when Closed Loop mode is activated.

## 5 <Motor Settings> tab

### Display

The general motor parameters are set in the <Motor Settings> tab.

### Parameter descriptions

The following parameters can be set for the motor:

Parameter	Function	Note
<b>hardware</b>		
Controller Type	Selection of controller type.	The user interface is modified to correspond to the selected controller type.
Motor Design	Selection of the motor design of the connector motor.	When a BLDC motor is selected, the input field for the pole pair number is displayed instead of the selection field for the drive step angle in the motor settings area.
Motor Type	Selection of motor type.	
Motor Name	Selection of motor designation	
Wiring	Selection of the wiring (serial or parallel)	

Parameter	Function	Note
<b>Motor settings</b>		
Step mode	<p>The following step modes can be selected:</p> <ul style="list-style-type: none"> <li>• Full step</li> <li>• Half step</li> <li>• Quarter step</li> <li>• Fifth step</li> <li>• Eighth step</li> <li>• Tenth step</li> <li>• 16th step</li> <li>• 32nd step</li> <li>• 64th step</li> <li>• Feed rate</li> <li>• Adaptive microstep</li> </ul>	<p>The smaller the selected step size is, the larger the resolution:</p> <p>With 1.8° stepper motors, a half step is therefore 0.9° and a tenth step 0.18°, for example.</p> <p>Adaptive microstep means that the step angle automatically increases with increasing speed.</p> <p>Example: at 30 rpm, the motor runs in 64th step mode and at 3000 rpm at full step as a higher speed is possible here and in general accuracy plays a subordinate role.</p> <p>In the Feed Rate mode, the number of full steps is defined by the feed rate.</p>
Drive Step Angle (Full Step step width) (not for BLDC motors)	Setting of the step angle of the connected motor.	<p>In general, the motor is a 1.8° stepper motor (default).</p> <p>Another step angle can be selected if necessary in the selection menu.</p>
Pole pairs (only for BLDC motors)	Entry of the pole pair number of the connected motor.	Only displayed if a BLDC motor is selected.
Phase Current	<p>The phase current can be set in steps of 1%.</p> <p>The corresponding absolute value is automatically calculated and displayed in the "Current" and "Peak Current" display fields.</p>	The peak current is lower in the full step mode than in the other step modes. To provide the same power as in the full step mode, the motor requires a higher peak current at smaller step modes.
Phase Current During Idleness	<p>Input of phase current at standstill in percent.</p> <p>The corresponding absolute value is automatically calculated and displayed in the "Current" and "Peak Current" display fields.</p> <p>It is recommended to select the highest possible current reduction for standstill.</p>	<p>This current reduction serves to minimize the heat generated by the dissipation loss of the motor windings and the output stage of the controller.</p> <p>When the full holding torque is required at a standstill, however, then the current reduction should not be activated and the phase current should not be reduced.</p>
BLDC I (max)	Entry of the peak current for BLDC motors in percent.	The peak current must be at least as large as the phase current; otherwise, the phase current is used.



Parameter	Function	Note
BLDC T (l)	Entry of the current time constants for BLDC motors in milliseconds.	The time constant defines the duration for which the set peak current can flow.
Reverse Clearance	Entering a number of steps to compensate for the reverse clearance of the mechanics, e.g. for linear axles or gears.	The steps entered here are added to every change of direction.
Reverse encoder direction of rotation	Option field for activating the encoder reversal of direction of rotation.	In some cases a false direction of rotation is defined. This can be seen when the error message "Position error" is always displayed when testing records. This function can be used to change the A/B track in the software.
Send State Byte Automatically Upon End of Record	If this option field is activated, status bytes are automatically sent at the end of a run.	The use of this option is sensible if just one motor is actuated and the end of the run must be evaluated. <b>Note:</b> This option may not be used under any circumstances if a network is in use, as this could lead to conflicts and therefore to transmission errors.
Rotation Encoder Resolution	<ul style="list-style-type: none"> <li>Resolution of the rotation encoder (pulses/revolution)</li> </ul>	The following resolutions can be selected: 500, 192, 200, 400, 512, 1000, 1024, 2000, 2048
Feed Rate Numerator	<ul style="list-style-type: none"> <li>Entry of the numerator of the feed rate.</li> <li>This value defines the number of steps per rotation of the motor shaft for the feed rate step mode.</li> </ul>	The feed rate is only used if numerator and the denominator are not equal to 0. Otherwise, the encoder resolution is used. Values for the feed rate that are not meaningful are not accepted when entered.
Feed Rate Denominator	<ul style="list-style-type: none"> <li>Entry of the denominator of the feed rate.</li> <li>This value defines the number of steps per rotation of the motor shaft for the feed rate step mode.</li> </ul>	The feed rate is only used if numerator and the denominator are not equal to 0. Otherwise, the encoder resolution is used. Values for the feed rate that are not meaningful are not accepted when entered.
Quick Stop Ramp	Ramp gradient for the Quick Stop function in Hz/ms.	Value range: 21.84 to 4230.95 Hz/ms
Speedmode Control	Selection of the control behavior in CL speed mode.	Please also refer to Section 13 "<CL-Parameter> (Closed Loop) tab".

## Adjusting the encoder

**Note:**

Before adjusting the encoder, the motor type or the motor step angle must be correctly set, see Section 5 "<Motor Settings> tab".

Resolution and direction of rotation of the encoder can be adjusted using the <Encoder Wizard>.

The motor makes one revolution if the button is pressed. The resolution of the rotation encoder is automatically matched and displayed in the <Motor Settings> tab. Depending on the connection, the rotation is also matched if necessary and displayed in the <Motor Settings> tab ("Reverse Encoder Direction" checkbox is activated).

## 6 <Brake> tab

### Display

Settings for the brake are adopted using the <Brake> tab.


The screenshot shows the 'Brake' configuration window. On the left, there are three input fields: 'Time ta' (0 ms), 'Time tb' (0 ms), and 'Time tc' (0 ms). Below these is a 'Save Data' button. The right side features a timing diagram with three horizontal axes: 'Start', 'Motor', and 'Bremse'. The 'Start' signal is a square wave. The 'Motor' signal is high when 'Start' is high and low when 'Start' is low. The 'Bremse' signal is high when 'Start' is high and low when 'Start' is low. Vertical dashed lines mark the times  $t_a$ ,  $t_b$ , and  $t_c$ . The 'Bremse' signal is labeled 'geschlossen' (closed) when high and 'geöffnet' (open) when low. The x-axis is labeled 'Zeit' (Time).

### Parameters for external brake

The following parameters can be set:

- **Time  $t_a$ :**  
Waiting time between switching on the motor current and switching off (triggering) the brake in milliseconds.
- **Time  $t_b$ :**  
Waiting time between switching off (triggering) the brake and activation of readiness in milliseconds. Travel commands will only be executed after this waiting time.
- **Time  $t_c$ :**  
Waiting time between switching on the brake and switching off the motor current in milliseconds.

The parameters indicate times between 0 and 65,536 milliseconds.  
Default values of the controller after a reset: 0 ms.



### Braking response

When switching on the controller, the brake becomes active first and the motor is not provided with power.


**Note:**

During current reduction, the brake is not actively connected.

## 7 <Display Properties> tab


### Display

Display properties are made using the <Display Properties> tab.



### Display Properties


The following parameters can be set:

Parameter	Function	Note
Distance	The distance can be displayed in: <ul style="list-style-type: none"> <li>• Steps</li> <li>• Degrees</li> <li>• mm</li> </ul>	The units of measure set here are inserted in the parameter fields of the various operating modes.
Speed	The speed (rotational speed) can be displayed in: <ul style="list-style-type: none"> <li>• Hz</li> <li>• rpm</li> <li>• mm/s</li> </ul>	The units of measure set here are inserted in the parameter fields of the various operating modes.
Position	The counter reading can be displayed in: <ul style="list-style-type: none"> <li>• Steps</li> <li>• Degrees</li> <li>• mm</li> </ul>	The units of measure set here are inserted in the parameter fields of the various operating modes.
Feed Rate	Definition of the feed rate in mm/rev.	If one of the above parameters is set to "mm", then the corresponding feed must be entered in the "Feed Rate" field.
Gear Reduction	Option field for activating the "Gear Reduction" field. Input of gear reduction if field activated.	When the option field is set, the field "Gear Reduction" is activated and the reduction value can be entered. 
Position Polling	Update interval for the ramp graph in ms in the <Movement Mode> tab.	On older computers it can make sense to set a high value. The default setting is 200 ms.

## 8 <Errorcorrection> tab

### Display

The settings for speed monitoring and error correction are made on the <Errorcorrection> tab.



### Motor function test

The motor has an integrated encoder signal evaluation for checking motor functions and to signal step losses. If the motor loses more than 1 half step (0.9° with a 1.8° stepper motor), output 2 signals an error.

It is possible to compensate for this error at the end of or during the run.

### Parameter descriptions

The following parameters can be set for the motor:

Parameter	Function	Note
Rotation Encoder Monitoring	The following modes can be selected: <ul style="list-style-type: none"> <li>• Deactivate</li> <li>• At end of run</li> <li>• During run</li> </ul>	"Deactivate" means that the rotation encoder monitoring has been switched off. All fields in this area are switched to inactive. The "Disable" mode must be selected if no encoder is being used. The rotation encoder monitoring mode checks the position of the rotor at the end of the run (after the swing out time) or during the run. As described above, the position of the rotor can also be checked and corrected, if necessary, at the end of the run if the "Automatic Errorcorrection" option field is activated.


Parameter	Function	Note
Swing Out Time	<p>Definition of a swing out time in 1 ms steps; the time that the encoder waits before it measures the position of the rotor.</p> <p>The recommended standard value is 80 ms.</p>	<p>After a record is completed, the rotor swings out around the set target position before it comes to a standstill. This swing out is taken into account with the definition of a swing out time, in order to avoid possible measurement errors.</p> <p>The swing out time decreases the smaller the moment of inertia of the rotor, and other external moments of inertia are, and the larger the damping, system rigidity and friction are.</p>
Tolerance Width	<p>Input of a tolerance within the encoder edges.</p> <p>The recommended standard value is 2 edges.</p>	<p>The tolerance is the maximum deviation in (micro)steps. How large a step is depends on the currently set step mode.</p> <p>If the encoder resolution is insufficient (step mode &gt; 1/10 in 1.8° motors, or. &gt;1/5 in 0.9° motors), additional errors will result from the conversion of encoder increments into microsteps.</p>
Automatic Errorcorrection	Option field for activating automatic error correction	<p>At the end of a record, the controller calculates the lost steps and compensates for them with a defined correction run. The parameters must be selected so that the controller safely implements the correction without losing any steps.</p> <p>When the setting is during the run, the correction will be implemented during the run itself.</p>
Record for errorcorrection	<p>Selection menu for definition of travel profile used for "Automatic Errorcorrection" (activated option field, see above).</p>	The ramp and the speed from the selected travel profile selected here are used for the correction run.

### Starting within the swing out time

The specification of a swing out time before measurement of the rotor position by the encoder limits the possibility of rapid reversing movements.

In the relative positioning mode, a break between two reversing rotations must also be set (minimum = 1 ms). If the set break is shorter than the swing out time, the motor waits until the rotor is in a suitable position and then carries out the next record. This "favorable position" is determined when the tolerance width is set and avoids step losses.

The length of the break and swing out time (in ms) after the completion of a record is determined by the number of encoder edges. It is possible to realize rapid reversing movements with the specification of a tolerance width (in edges).



### Encoder edges

The encoder has a 5 to 10 times higher resolution than the motor. The encoders used operate with 500 pulses/revolution.

This squaring results in a resolution of 2,000 edges.

The 1.8° stepper motors operate with 200 steps/revolution, therefore a full step equals 10 encoder edges (half step = 5 edges).

The recommended tolerance width is 2 edges.




## 9 <Input> tab

### Display

### Analog input

The <Input> tab, the following parameters for the analog input can be defined:

Parameter	Function
Lower Limit and Upper Limit	<p>These values determine the upper and lower limits of the input voltage.</p> <p>The voltage is resolved with an accuracy of 10 bits. The smaller the selected range is, the worse the resolution of the speed will be (and vice versa):</p> <ul style="list-style-type: none"> <li>• Start speed: lower limit</li> <li>• Setpoint speed: upper limit</li> <li>• Maximum range: -10 V ... +10 V.</li> </ul> <p><b>Calculation example</b>                      Selected voltage range = 0 V to +5 V                      Start speed = 400 Hz = 0 V                      Setpoint speed = 1000 Hz = +5 V                      Speed adjustable:  <math>10 \text{ bit} = 1024 = 5 \text{ V} / 1024 = 0.0048 \text{ V}</math> corresponds to 2.344 Hz  <math>(400 \text{ Hz} - 1000 \text{ Hz} = 600 \text{ Hz} / 256 = 2.344 \text{ Hz})</math>.</p> <p>The divisor "256" in the above equation is derived from the percentage of the voltage range used:                      The voltage range of 5 V out of a possible range of 20 V equals 25%. Based on the 10 bit resolution, this is equal to 25% of 1024 = 256.</p>

Parameter	Function
Play (dead range)	<p>The "Play" setting provides an option to hide the interference or ripple voltage in the lower limit range.</p> <p>A play of 10% would limit the control range to 0.5 – 5.0 V with a lower limit of 0 V and an upper limit of 5 V.</p>  <p><b>Calculation example for play:</b>                  Selected voltage range = 0.5 V to +5 V                  Start speed = 400 Hz = 0.5 V                  Setpoint speed = 1000 Hz = +5 V                  Speed adjustable:  <math>10 \text{ bit} = 1024 = 4.5 \text{ V} / 1024 = 0.0044 \text{ V}</math> corresponds to 2.604 Hz  <math>(400 \text{ Hz} - 1000 \text{ Hz} = 600 \text{ Hz} / \mathbf{230.4} = 2.604 \text{ Hz})</math>.                  Divisor from the percentage of the voltage range used:                  The voltage range of 4.5 V out of a possible range of 20 V equals 22.5 %. Based on the 10 bit resolution, this corresponds to 22.5% of 256 = 230.4.</p>
Filter	<p>The analog input samples the input voltage with a frequency of 1 kHz. The input voltage can be smoothed with the help of the analog input.</p> <p>A filter value between 0 and 16 results in a simple average value formation over the given number (a value of 0 or 1 indicated that averaging has not occurred).</p> <p>As filtering only takes 16 milliseconds with a sample frequency of 1 kHz over maximum 16 supporting points, it is possible to use a recursive filter where the determined value depends on the actually measured value and on the previous "filter value". This method can be used to average a greater number of supporting points, even if insufficient memory is available. However, this is not a real average value, but a signal rounding of the input voltage (first order low pass or PT1 element).</p> <p>The recursive filter is used from a value of 17. The first 4 bits of the value as a power of 2 define the time constant T in ms (time after which the filter output has approached the filter input to within 50%) and the last 4 bits of the value define the hysteresis (maximum change of the value at the filter input toward which the filter output is insensitive). The two components of the filter setting can be separately set using the two sliders; the corresponding total value is automatically entered in the "Filter" field. The following table shows the values of the time constant for a hysteresis of 0.</p> <p>With an input jump from 0 to 1, the filter output follows the following rule: <math>\text{Output} = 1 - (0.5)^{t/T}</math>                  where t is the time along the x axis and T the time constant of the filter.</p> <p>5*T after changing the input voltage, the value at the filter output has thus reached 97% of the input value.</p>

Parameter	Function		
	10*T after changing the input voltage, the value at the filter output will have reached 99.9% of the input value. The deviation corresponds to one stage of the AD converter when the input changes cover the entire range, e.g. a jump from -10 V to +10 V.		
	Value	Time constant T	Time for 99.9%
	17	1 ms	10 ms
	18	2 ms	20 ms
	19	4 ms	40 ms
	20	8 ms	80 ms
	21	16 ms	160 ms
	22	32 ms	320 ms
	23	64 ms	640 ms
	24	128 ms	1.2 s
	25	256 ms	2.6 s
	26	512 ms	5.1 s
	27	1 s	10 s
	28	2 s	20 s
	29	4 s	40 s
	30	8 s	80 s
	31	16 s	160 s
Time constant / hysteresis			


### Behavior for Internal / External Homing

There are various options for defining behavior at the external and internal limit switches:

- "Free backwards" (reference run and normal operation)
- "Free forwards" (reference run and normal operation)
- "Stop" (only for normal operation)
- "Disable" (only for normal operation)


### "Free backwards"

The motor changes direction on recognition of the limit switch and leaves the limit switch.




### "Free forwards"

The motor continues in the same direction after recognizing the limit switch and leaves the limit switch.



## "Stop"

The motor immediately stops upon recognition of the limit switch. A reference run must then be implemented as the motor may have lost steps (overflow).



## "Disable"

The limit switch has no function.

The following parameters can be set:

Parameter	Function
Type	Selection of the reference switch as an opener or closer depending on the version.
During Homing	Data on whether the limit switch (external and internal) should be approached during the reference run free forwards (without direction change) or backwards (in the opposite direction).
During Normal Operation	Data on how the motor should behave when recognizing the limit switch (external and internal) during normal operation (no reference run).

## Procedure

Proceed as follows to set the limit switch behavior:



Step	Action	Note
1	Select the <Input> tab.	
2	Set the parameters according to your requirements.	
3	Click on the <Save Data> button.	The settings are saved.

## Inputs

The following settings can be made:

### Switching behavior

A selection can be made for each input as to whether it switches with rising or falling edge:

-  = falling edge
-  = rising edge

### Input function

- User defined:  
 The input is "masked", i.e. it is not directly interpreted by the controller and is available to the user as a "general purpose" input.  
 The masking of an input means that its state (high/low) can be evaluated via the interface.  
 Further information can be found in the relevant "Command Reference" section of the programming manual.
- Start/reset:  
 An impulse at the Start/Reset input starts the selected travel profile. A negative edge at Start/Reset input can be used to reset an error (speed monitoring).
- Record bit 0 to record bit 4:  
 The profile numbers are called up using a binary code with the inputs record bit 0 to record bit 3. When the Start/Reset input is activated, the value is read in and the corresponding profile is loaded and started.

Profile number	Record bit 0	Record bit 1	Record bit 2	Record bit 3	Record bit 4
1	0	0	0	0	0
2	1	0	0	0	0
3	0	1	0	0	0
...	...	...	...	...	...
31	0	1	1	1	1
32	1	1	1	1	1

- External reference switch:  
 See "End switch behavior, internal/external" and the separate manual for the respective stepper motor control or for the Plug & Drive motor.
- Trigger:  
 A pulse at the trigger input starts the positioning mode in the clock direction mode.
- Direction:  
 The Direction input determines the direction of rotation of the motor.  
 In the Joystick mode, the direction of the motor depends on the defined voltage range. The direction is changed in the middle of the voltage range (e.g. at +5 V in a voltage range of 0 V to +10 V).
- Enable
- Clock (input 6 only):  
 With every positive edge at the clock input, in the Clock direction mode the motor carries out a step in the direction set by the direction input. The external clock is also active for the reference runs.
- Clock direction mode, mode selection 1/2:  
 The mode is defined with the clock direction mode, mode selection 1/2 inputs. The setting is accepted when the Start/Reset input is activated. The direction of the

reference runs is specified by the saved parameters. In the clock direction left/right modes, the motor travels 10 steps with a frequency of approx. 2 Hz and then accelerates to the programmed maximum frequency.

Mode selection

<b>Operating mode</b>	<b>Clock Direction mode, mode selection 1</b>	<b>Clock Direction mode, mode selection 2</b>
Clock Direction Left	0	0
Clock Direction Right	1	0
Clock Direction Run Int. Ref.	0	1
Clock Direction Run Ext. Ref.	1	1

### State Display

In addition, the state of the inputs present when the tab was opened is displayed (green = high, red = low).

### Input Debounce Time


Sets the time in ms that needs to elapse after a signal change at an input until the signal has stabilized.

### Activate Input Polling

The status display of the inputs is activated if the checkbox is activated.

## 10 <Output> tab

### Display



**Note:** The number of outputs depends on the controller in use.

### Settings

The following settings can be made:

#### Switching behavior

A selection can be made for each output whether it switches with rising or falling edge:

- = falling edge
- = rising edge

#### Output function

- User defined:  
The output is "masked", i.e. it is not directly interpreted by the controller and is available to the user as a "general purpose" output.
- Ready
- Running

"Ready"	"Running"	State
0	1	Motor processing last command.
1	0	Motor idle, waiting for new command.
0	0	Error (speed monitoring) or limit switch (normal operation).
1	1	Reference point (zero position) reached.



### **Setting the output**

When the checkbox is activated, the corresponding output of the firmware is set provided it is masked for open use.

### **State Display**

In addition, the state of the outputs present when the tab was opened is displayed (green = high, red = low).


### **Activate Output Polling**

The status display of the outputs is activated if the checkbox is activated.

# 11 <Communication> tab

## Display

The settings for interface parameters and the motor address made on the <Communication> tab:



## Interface parameters

The following interface parameters can be set:

Parameter	Function
Port	In the "Port" field, select the COM port to which the motor is connected. <ul style="list-style-type: none"> <li>The number of the COM port to which the motor is connected can be found in the device manager of your Windows PC.</li> </ul>
Write/Read Timeout	Maximum timeout in milliseconds when transferring data to/from the controller.
Baud rate	Data transfer rate in bits per second.

## Setting the drive address

To ensure a fault-free connection with the motor, the motor address (module address) must be set correctly. All motors are delivered with the default address "1". To operate more motors in an RS485 network, each motor must be assigned a unique address.

The following functions are available in this menu:

- <Check Drive Address>  
Press the button to check whether a motor is connected to the currently configured motor address.
- <Search Drive Address>  
Prerequisite: Only one motor is connected.  
The address of the connected motor is adopted.
- <Change Drive Address>  
Prerequisite: Only one motor is connected.  
The "drive address" configured in the selection menu is assigned to the motor.
- <Choose Drive Address> The address configured in the "Drive Address" selection menu is transferred to the "Motor" selection menu (menu bar).

**Change Drive Baudrate**

Select the required baud rate from the "Drive Baudrate" selection menu and then click on the <Save Settings> button to transfer the new setting.

**Activating the communication check with CRC**

Activate the "Check Communication with CRC" checkbox and then click on the <Save Settings> button to verify communication between the PC and controller using a checksum.

**Search Controller**


When the <Search Controller> button is activated, all COM ports and baud rates are run through until a controller is found.

## 12 <Statusdisplay> tab

### Introduction

The <Statusdisplay> tab can display general status messages, stored error entries and programming settings can also be made.

### <Statusdisplay> tab



### Display

The <Statusdisplay> tab contains the following displays:

Display	Function
Encoder Position	Actual encoder position (if an encoder is connected)
Demand Position	Current setpoint position of the motor
State Display	Actual mode, state and last error entry
Closed Loop Status	Indicator of whether closed loop mode is active
Error Display	Error memory for the last 32 errors. Note: After the controller is switched on, the "Undervoltage" error message appears with the error position 13. Because the undervoltage occurs with the last switch-off of the controller, this error message is entirely normal.

### Activating the status display

Proceed as follows to activate the motor status:

Step	Action	Note
1	Select the <Statusdisplay> tab.	
2	Activate the "Activate Polling" checkbox.	

### Programming settings

Controllers can be programmed via JAVA (NanoJEasy) or via the COM interface, see the programming manual.

The following settings can be made in the "Programming Language" area:

Setting	Function
Autostart	When the checkbox is activated, the loaded program is automatically executed if the motor is powered.
Activate Com-Polling	If this checkbox is activated, any responses of the executed program via the COM interface are displayed in the field under the checkbox.
Start program/Stop program	Starts/Stops the loaded program.
Read Error	Displays the last entry of the error memory.
NanoJEasy	Open the NanoJEasy editor (if installed).
Transfer program	Transfer the program to the controller.

# 13 <CL-Parameter> (Closed Loop) tab

## 13.1.1 Configuring the Closed Loop current control


### Function

In the Closed Loop mode, the motor does not behave like a normal stepper motor, but instead like a servomotor. It is controlled via a PID controller dependent on an encoder.

The controller includes two controllers and each controller has its own parameter set.

### <CL-Parameter> tab

Settings for the Closed Loop current control are made via the <CL-Parameter> tab.



### Procedure

Proceed as follows to configure the Closed Loop current control:

Step	Action	Note
1	Select the <CL-Parameter> tab.	
2	In the "Load Defaultsettings" field, select the motor size (e.g. ST41xx)	
3	Run the Closed Loop wizard in the "CL - Wizard" button.	<b>CAUTION!</b> Motor makes several revolutions. See Section "CL - Wizard".
4	Run the Autotuning Wizard in the <Autotuning-Wizard> button.	The wizard empirically determines suitable CL parameters. Alternatively, you can also enter them manually as described in Step 4.
5	Enter the desired parameters.	Detailed information on the parameters can be found the following sections.
6	Click on the <Save Data> button.	The settings are saved.

## 13.1.2 Velocity Loop

### Description

The speed controller controls the angle speed of the shaft. The position in this mode is not controlled and can therefore deviate greatly from the setpoint.

The speed controller is used in the following operation modes:

- Speed mode
- Analog mode
- Joystick mode
- Rotor position measurement

### Internal calculation principles and parameters

The controlled variables in the speed controller are always based on the actual speed in revolutions per minute (rpm). The set parameters are used to convert the system deviation (deviation of actual speed from setpoint speed) into the control variable (current value).

The control variable of the speed controller is determined with the following equation:

$$u_n = KP * e_n + I_{n-1} + KI * e_n + KD * (e_{n-1} - e_n)$$

The next integral value is derived from:

$$I_n = I_{n-1} + KI * e_n$$

$u_n$	Control variable
$KP$	Proportional component derived from the numerator/ 2 <sup>denominator</sup>
$KI$	Proportional component derived from the numerator/ 2 <sup>denominator</sup>
$KD$	Proportional component derived from the numerator/ 2 <sup>denominator</sup>
$e_n$	Deviation of actual value from setpoint value
$e_{n-1}$	Deviation of previous actual value from previous setpoint value
$I_{n-1}$	Last integral value

### Speed error monitoring

The speed controller monitors the set speed. If the actual speed deviates for a specific time from the setpoint speed, the controller is deactivated and the motor stops.

The speed monitoring can be adjusted as required with the parameters in the "Following Error Speed Mode" area:

- "Count" The maximum amount-based deviation of the actual from the setpoint position is output in steps (value range: 0 - 2000000000).
- "Time" Time is output in milliseconds.

### 13.1.3 Position Loop

#### Description

The position controller controls the position. It is used in the following modes:

- Relative/Absolute Position Mode
- Flag Position mode
- Clock Direction mode
- Analogue Position mode
- Reference run

#### Internal calculation principles and parameters

With the position controller, the controlled variables always refer to the actual position deviation in steps. The set parameters are used to convert the system deviation (deviation of actual position from setpoint position) into the control variable (current value). The set parameters are used to convert the system deviation (deviation of actual position from setpoint position) into the control variable (current value).

The control variable of the position controller is determined with the following equation:

$$u_n = KP * e_n + I_{n-1} + KI * e_n + KD * (e_{n-1} - e_n)$$

The next integral value is derived from:

$$I_n = I_{n-1} + KI * e_n$$

$u_n$	Control variable
$KP$	Proportional component derived from the numerator/ 2 <sup>denominator</sup>
$KI$	Proportional component derived from the numerator/ 2 <sup>denominator</sup>
$KD$	Proportional component derived from the numerator/ 2 <sup>denominator</sup>
$e_n$	Deviation of actual value from setpoint value
$e_{n-1}$	Deviation of previous actual value from previous setpoint value
$I_{n-1}$	Last integral value

#### Reaching the end position

If the position controller is active, the motor will only signal that it is ready after the end of a run when the measured position remains within a tolerance window for a specific time.

The tolerance width and the minimum time can be set with the parameters in the "Position Error" area:

- "Count" The maximum amount-based permissible deviation from the end position is output in steps.
- "Time" The minimum time in milliseconds that the motor must stay at the corresponding position before it signals that it is "ready".



### Position error monitoring

The position controller monitors the set position at all times (even following errors are recorded during travel). If the actual position deviates by a specific value from the setpoint position, the controller is deactivated and the motor stops.

The position monitoring can be adjusted as required with the parameters in the "Following Error Pos Mode" area:

- "Count"      The maximum amount-based deviation of the actual position from the setpoint position is output in steps. (Value range: 0 - 200000000).
- "Time"        Time is output in milliseconds.

### Help for setting the control parameters of the position controller

To adjust the parameters, it is necessary to apply the load that the controller later needs to control to the motor. It does not make sense to set the controller for an unloaded motor as the behavior will change completely when the load is applied to the motor.

The following table shows possible problems and countermeasures:

Problem	Countermeasures
Motor oscillates up or too long afterwards.	<ul style="list-style-type: none"> <li>• Reduce I-component</li> <li>• Increase D-component</li> <li>• Increase P-component</li> </ul>
Motor "cracks" during the run.	<ul style="list-style-type: none"> <li>• Reduce D-component</li> <li>• Possibly reduce P-component</li> </ul>
Motor takes too long to reach the end position.	<ul style="list-style-type: none"> <li>• Increase I-component</li> <li>• Increase P-component</li> </ul>
Motor compensates for static loads too slowly	<ul style="list-style-type: none"> <li>• Increase I-component</li> </ul>
Motor signals position error.	<ul style="list-style-type: none"> <li>• Increase permissible following error ("Following Error Pos Mode").</li> <li>• Operate controller more firmly (increase P-component, increase I-component).</li> <li>• Decrease maximum speed.</li> <li>• Increase phase current.</li> </ul> <p><b>CAUTION!</b> Note maximum motor current. A new rotor position initialization may be necessary.</p>
Motor not accelerating as fast as the set ramp (possibly combined with a position error during the acceleration phase).	<ul style="list-style-type: none"> <li>• Increase phase current.</li> </ul> <p><b>CAUTION!</b> Note maximum motor current.</p> <ul style="list-style-type: none"> <li>• Set a slower ramp.</li> <li>• Use a stronger motor (with appropriately set phase current).</li> </ul>


**Cascade controller**

The cascade controller consists of two closed loops: an internal closed loop that controls the speed, and an external closed loop that controls the position. The external closed loop does not directly control the motor current, but the setpoint value (setpoint speed) of the internal closed loop.


The autotune wizard can also be used to empirically determine the control parameters for the cascade controller.



**CL - Wizard**



Start the closed loop wizard with which the closed loop mode can be set up using the <CL - Wizard> button.



	<p><b>CAUTION!</b></p> <p>Motor makes several revolutions.</p> <ul style="list-style-type: none"> <li>• Ensure that a motor is connected.</li> <li>• Check the interface parameters in the &lt;Communication&gt; tab!</li> </ul>
---	--



Proceed as follows:


Step	Action
1	<p>Click on the &lt;CL - Wizard&gt; button. The following window appears:</p> 

Step	Action
2	<p>Click on the &lt;Next&gt; button. The following window appears:</p> 
3	<ul style="list-style-type: none"> <li>• If a configuration file already exists: Select the upper option field and then click on the &lt;Next&gt; button. The "Open" window appears, in which you can select the configuration file.</li> <li>• If configuration file still does not exist: Click on the &lt;Next&gt; button. A search is made for connected hardware. The following window appears if hardware has been found:</li> </ul>  <p>Check whether the hardware has been detected correctly and change the motor design, motor type, wiring and step angle/pole pair number if necessary.</p>

Step	Action
4	<p>Click on the &lt;Next&gt; button. The following window appears:</p>  <p>Specify the phase current in %.</p> <p><b>Note:</b> An excessively high phase current can damage your motor. See the phase current data in the data sheet of your motor.</p>
5	<p>Click on the &lt;Test drive&gt; button if necessary. The following window appears:</p>  <p>Click on the &lt;Ok&gt; button: An attempt is made to move the motor by one rotation using the specified parameters. Click on the &lt;Cancel&gt; button to abort the motor test.</p>

Step	Action
6	<p>The following window appears after the motor test:</p>  <p>Check whether the connected motor has made a full revolution. Change the settings for the step angle or motor current if necessary.</p> <p><b>Note:</b> Depending on the selected motor design, the automatic encoder detection and calibration run (step 8) can be omitted.</p>
7	<p>Click on the &lt;Next&gt; button. The following window appears:</p>  <p>Check whether the encoder resolution was detected correctly and change the value in the upper selection menu if necessary. In BLDC motors, the encoder resolution cannot be detected automatically and therefore must be set by the user. Then select a parameter set in the lower selection menu if necessary.</p>

Step	Action
8	<p>Click on the &lt;Next&gt; button.                      A calibration run is then performed. The following window appears during the process:</p>  <p>The following window appears after the successful calibration run:</p>  <p>Check the measurement results of the calibration run.</p>

Step	Action
9	<p>Click on the &lt;Next&gt; button. The following window appears:</p>  <p>Activate the checkbox if the configuration file should be saved.</p>
10	Click on the <Finish> button to complete the Closed Loop Wizard.

### Autotune Wizard

Using the <Autotuning-Wizard> button, start the autotune wizard that can be used to empirically determine suitable control parameters.

Please ensure that you have fully executed the closed loop wizard before starting the autotune wizard.





#### **CAUTION!**



Motor haltingly makes several revolutions. Possible damage to the system in which the motor has been installed.

- Ensure that a motor is connected.
- Check the interface parameters in the <Communication> tab!

Proceed as follows:

Step	Action
1	<p>Click on the &lt;Autotuning - Wizard&gt; button. The following window appears:</p> 
2	<p>Click on the &lt;Next&gt; button. The following window appears:</p> 
3	<p>Adjust the following parameters if necessary:</p> <ul style="list-style-type: none"> <li>• Drive direction: direction of rotation in which the autotune run takes place.</li> <li>• Control loop gradient: proportional factor for sharpness of the controller in area 0.1 to 10. Value &lt; 1: controller weaker Value = 1: controller neutral Value = &gt;1: controller sharper</li> <li>• Maximum way: maximum distance that is covered during an autotuning run.</li> <li>• Maximum speed: speed to which the motor accelerates during an autotuning run.</li> <li>• Phase Current: current that is applied to the motor during the autotuning run.</li> </ul>



Step	Action
4	<p>Click on the &lt;Next&gt; button.</p> <p>An autotuning run is performed. The following window appears after the procedure:</p>  <p>The following window appears after the autotuning run if applicable:</p>  <p>The specified maximum way may have been too short to reach the specified maximum speed. Try to increase the way or to reduce the speed or current.</p>
5	Click on the <Finish> button to complete the autotuning wizard.
6	Click on the <Save Data> button to save the determined parameters in the controller.


## 14 <Scope> tab

### Function

In scope mode, important motor parameters can be displayed and recorded during a run. This is primarily used to check the set parameters or the commissioning of a drive.

### Display

The scope mode settings are made in the <Scope> tab.



### Selectable parameters

#### “Target position” and “Current position” parameters

The **target position** is the target value calculated by the ramp generator of the motor.

The **current position** is the position determined with the help of the motor encoder. In normal cases, the target and current positions should match. The current position is the position determined with the help of the motor encoder. In normal cases, the target and current positions should match. The current position is always 0 in a motor without encoder. If the target and current position deviate from one another, this may be due to various reasons: If the target and current position deviate from one another, this may be due to various reasons:

- Step loss during the run: When the motor does not reach its target position during open loop operation, step losses have occurred. Possible countermeasures:
  - Select a flatter ramp
  - Select a lower speed
  - Increase motor current so that the motor has more strength

- Incorrect setting of the encoder: When the curves for setpoint and actual position are mirrored during a run, the rotation direction of the encoder is inverted (e.g. run of 400 steps, then setpoint position 400 and actual position -400).  
Countermeasure: Reverse the rotation direction of the encoder in the <Motor Settings> tab.

**CAUTION!**

To have these settings accepted for closed loop operation, the motor must be disconnected from the power supply.

When the curves are identical in direction, but differ in gradient, then the resolution of the encoder is incorrect.

Counter measure: Adjust the encoder resolution in the <Motor Settings> tab.

**Other parameters**

Parameter	Description
Following error	The following error indicates the difference between the target and actual position. If the following error exceeds the set value, the motor will output a position error. For the open loop mode, the limit value can be set in the <Errorcorrection> tab. The following error indicates the difference between the target and actual position. If the following error exceeds the set value, the motor will output a position error. For the open loop mode, the limit value can be set in the <Errorcorrection> tab. For the closed loop mode, there are separate values for the speed mode and the positioning mode. They can be set in the <CL - Parameter> tab. They can be set in the <CL - Parameter> tab.
Target Current	The "Target Current" value specifies the set phase current in open loop mode. In closed loop mode, the current calculated by the motor is displayed.
Actual Voltage	Indicates the voltage applied to the motor.
Temperature	Indicates the temperature measured by the motor.
Analog input	Indicates the voltage at the analog input.
Digital Inputs	Sets the level of all digital inputs of the motor.

**Parameters for the Closed Loop mode**

Power	Indicates the power output by the motor.
Efficiency	Indicates the efficiency of the motor.
Current Drain	Indicates the current consumption of the motor.


## Display of parameters

### Activate/Deactivate

Activating the checkbox displays the progression of the respective parameter in the Scope mode.

### Color

The color with which the parameter is displayed can be changed by clicking on the colored box.



### Scaling

The scaling of the parameter is specified under the <Unit> button and can be changed with the arrow keys (to the left of the checkboxes).

Clicking on the <Unit> button changes its labeling to <Value>. The current parameter values are then displayed instead of parameter scaling when the Scope mode is running.

The horizontal axis can be changed in the ms grid using the <Time> slider.

## Adjustment parameters

The following settings can be made for the Scope mode:

Setting	Function
Sample Rate	Setting of the sample rate in milliseconds.
Voltage	Voltage with which the motor is driven.
Start Drive Profile	When the checkbox is activated, the travel profile currently set in the controller starts at the same time as the scope mode.

## Controlling the Scope mode

Reset Counter	Sets the travel profile to the zero position.
Start / Stop	Starts/stops the scope mode (travel profile 32).
Save	Saves recorded parameters.
Open	Opens recorded and saved parameters.
Screenshot	Creates a screenshot of the current display.

## 15 <Expert> tab

**Note:**  
Settings in the <Expert> tab should only be changed by experienced users who are familiar with working with stepper motors, Nanotec controllers and the NanoPro software.

### Display

Various expert settings can be made in the <Expert> tab.

The screenshot displays the NanoPro software interface with the <Expert> tab selected. The interface includes a menu bar at the top with options: Movement Mode, Motor Settings, Brake, Display Properties, Errorcorrection, Input, Output, Communication, Statusdisplay, CL - Parameter, Scope, and Expert. The main window is divided into several sections:

- Serial Interface:** A large empty text area for communication, with a 'Send Command' button and a 'Clear Log' button below it.
- Analog Input Correction:** Contains input fields for 'Offset' (set to -1) and 'Amplitude' (set to 32768), along with a 'Save Correction values' button.
- Miscellaneous:** Contains several parameters:
  - Encoder Index Offset: 0
  - Clockmode Interpolation Gradient: 320
  - CL Node Distance: 4096
  - Cascade Loop Start Frequency: 327680
  - Cascade Loop Stop Frequency: 512
- Loadangle Values:** Contains seven input fields:
  - Value 1: 16384
  - Value 2: 17000
  - Value 3: 17500
  - Value 4: 17750
  - Value 5: 18000
  - Value 6: 18000
  - Value 7: 18000
- PI Parameter DSP-Drive:** Contains six input fields:
  - P low: 1
  - P high: 1
  - P scale: 58
  - I low: 1
  - I high: 1
  - I scale: 200

A 'Save Data' button is located at the bottom left of the interface.

## Parameter descriptions

The following parameters can be set:

Parameter	Function	Note
<b>Serial interface</b>		
Send Command	Direct access to the control via the console.	For commands, see the programming manual.
Clear Log		
<b>Analog Input Correction</b>		
Offset	Offset of analog input.	Value range: -32768 to 32767 Default value: 0 The parameter is not stored in the XML configuration file and is only transferred to the controller by clicking on the <Save Correction values> values button, but not when the <Save Data> or <Save Configuration to Drive> button.
Amplitude	Amplification of analog input.	Value range: 0 to 65535 Default value: 32768 The parameter is not stored in the XML configuration file and is only transferred to the controller by clicking on the <Save Correction values> values button, but not when the <Save Data> or <Save Configuration to Drive> button.
<b>Miscellaneous</b>		
Encoder Index Offset	Specifies the mechanical offset of the encoder to the rotor.	Value range: -32768 to 32767 Default value: 0
Clockmode Interpolation Gradient	Specifies the maximum time in milliseconds after which an interpolated support threshold value is reached if a further clock signal does not take place before then.	Value range: 0 to 16383 Default value: 320
CL Node Distance	Distances of the individual load angles, where the value 8192 corresponds to 1000 rotations per minute.	Value range: 1 to 65535 Default value: <ul style="list-style-type: none"> <li>• Stepper motors: 4096</li> <li>• BLDC motors: differ by motor type.</li> </ul>
Cascade Loop Start Frequency	Frequency above which the cascade loop is active.	Value range: 0 to 2147483647 Default value: 327680

Parameter	Function	Note
Cascade Loop Stop Frequency	Frequency up to which the cascade loop is active.	Value range: 0 to 2147483647. Default value: 512
<b>Loadangle Values</b>		
Value 1 to 7	Lead values for the magnetic field.	Value range: -32768 to 32767 Default values: differ by motor type The value 65536 = 2 <sup>16</sup> for the load angle value corresponds to 360°.
<b>PI Parameter DSP-Drive (only with controllers with a dspDrive)</b>		
P low	P component of the current controller at a standstill	Value range: 0 to 1000 Default value: 1
P high	P component of the current controller during the run.	Value range: 0 to 1000 Default value: 1
P scale	Scaling factor for the speed-dependent adjustment of the P component of the current controller during the run.	Value range: 0 to 1000 Default value: 58 P component = P run + speed * P scaling
I low	I component of the current controller at a standstill.	Value range: 0 to 1000 Default value: 1
I high	I component of the current controller during the run.	Value range: 0 to 1000 Default value: 1
I scale	Scaling factor for the speed-dependent adjustment of the I component of the current controller during the run.	Value range: 0 to 1000 Default value: 200 I component = I run + speed * I scaling
<b>Hall mode</b>		
Value 1 to 6	Positions of Hall sensors.	For a detailed explanation, see Hall Mode Command in the programming manual.

## 16 Operating Several Motors

### Introduction


Up to 254 motors can be controlled in a network.

The motor address must be assigned in advance for each motor, see Section 11 "<Communication> tab".


New motors can be added in the "Motor" menu by clicking on the <Add Motor> button.

All the motors are displayed in the selection menu.

Unnecessary motors can be removed from the controller by clicking on the <Remove Motor> button.



### "Motor Address" menu



### Procedure

Proceed as follows to add new motors:

Step	Action	Note
1	Select the "Add Motor" menu item in the "Motor" menu.	The "Motor address" menu opens.
2	Enter a motor address for the motor (number).	Number 1 to 254.
3	Click on the <OK> button.	The settings are saved.

### Changing the motor address

The motor address may only be changed if exactly one motor has been connected. See Section 11 "<Communication> tab".



# 17 Troubleshooting

## 17.1 General information

### Error messages

The motor monitors specific functions and outputs an error message if there is a malfunction.

Error messages are displayed in a pop-up window, e.g.:



Descriptions of possible error messages can be found in Section 17.2 "Error messages".

### Troubleshooting procedure

Proceed with care during troubleshooting and error rectification to avoid damaging the motor.



#### **Danger of electrical surges**

An operating voltage of > 50 V (for SMCI12 a voltage of > 26 V, for SMCI36 a voltage of > 72 V) and incorrect connections can destroy the end stage.

Never disconnect the link when operating voltage is applied!

Never disconnect lines when live!

## 17.2 Error messages

### Communication error

This message appears when data transmission to the controller is not possible:




The following causes may be responsible:

- The wrong COM port is set (see Section 11 "<Communication> tab").
- The communication cable is not connected or interrupted.
- A nonexistent motor number is set.
- The voltage supply to the motor is interrupted.

### Controller is not ready

If inadmissible data is sent to the controller during the output of a travel profile, the following message appears:




Pressing the <Yes> button stops the travel profile and the controller switches back to the "Ready" state. Pressing the <No> button stops the travel profile and the controller switches back to the "Ready" state. The data can then be resent to the controller.

Pressing the <No> button allows the travel profile to continue.

### Position error


If a button is clicked while the motor is in error mode (position error or limit switch in normal operation), the following message is displayed.



The error can be reset by pressing the <Yes> button.

### Following error

If a button is clicked while the motor is in error mode (following error), the following message is displayed.



A following error occurs if the motor is in speed mode and either closed loop or error correction is activated and the actual value differs from the measured value.

The error can be reset by pressing the <Yes> button.

### Clock frequency

If an attempt is made to communicate with the controller, while the motor is presently operated in the Clock Direction mode with a clock frequency of more than 65 kHz, then the following message appears:



Communication can only take place again if a clock frequency of less than 65 kHz is set.

## Index

### A

Absolute positioning mode .....	18
Actual Voltage .....	75
Analog input.....	75
Analog mode .....	34
Analog Positioning mode.....	36
Automatic Errorcorrection.....	47
Autotune Wizard .....	71

### B

Baud rate .....	58
Brake .....	43
Brake Ramp.....	20
Break .....	20, 29

### C

Cascade controller.....	66
CL - Wizard.....	62
CL Parameter .....	62
Clock Direction mode .....	31
Closed-Loop current control .....	10, 41, 62
Communication.....	58
Correction run.....	47
Counter	
Read.....	17
Reset.....	16
Current Drain .....	75
Current position .....	74

### D

Delivery condition .....	17
Digital Inputs.....	75
Direction.....	20
Display Properties .....	43, 45
Distance.....	45
Drive	
Read from .....	16
Save to.....	16

Drive Step Angle .....	40
------------------------	----

### E

Efficiency.....	75
Encoder.....	46, 48
Encoder direction of rotation.....	41
Encoder position .....	60
End position tolerance .....	64
Error correction .....	46
Error Display .....	60
Error messages.....	81
External reference run .....	12, 18, 31, 51

### F

Feed rate.....	45
Filter .....	50
Firmware update .....	9
Flag positioning mode.....	27
Following error .....	63, 65, 75
Frequency	
decrease.....	24
increase.....	24

### G

Gear reduction .....	45
----------------------	----

### H

Hysteresis .....	51
------------------	----

### I

Input Debounce Time .....	55
Inputs .....	49
Installation.....	6
Internal reference run .....	12, 18, 31, 51

### J

Joystick mode .....	34
---------------------	----

### L

Limit switch behavior.....	51
During Homing .....	53

During Normal Operation .....	53	Torque mode .....	38
Type .....	53	Outputs .....	56
<b>M</b>		<b>P</b>	
Menu		Phase current.....	40
File .....	8	Play (dead range) .....	50
Help.....	9	Polling .....	61
Language .....	8	Port .....	58
Motor .....	8, 80	Position .....	45
System .....	9	Position Demand.....	20
Minimal speed .....	20	Position error monitoring.....	65
Motor		Position loop .....	64
Add.....	8, 80	Power .....	75
Change Drive Address.....	58	Profile graph.....	16, 22
Check Drive Address .....	58	programming language.....	61
Choose Drive Address.....	58	<b>Q</b>	
Copy to.....	8	Quick Stop .....	16
Define Address .....	80	<b>R</b>	
Refresh All Values .....	8	Ramp .....	20
Remove.....	8	Ramp Type .....	22
Save All Values.....	9	Read from Drive.....	16
Search Drive Address.....	58	Reference run .....	12, 18, 31, 51
Select .....	8	Relative positioning mode.....	18
Motor settings .....	10, 11, 15, 16, 39, 42	Repetitions .....	21, 29
Motor type.....	39	Reset Positions .....	76
<b>N</b>		Reverse Clearance .....	41
Network.....	80	Reverse direction .....	21
Next record .....	21	Rotation Encoder Monitoring .....	46
<b>O</b>		Rotation Encoder Resolution .....	41
Online help .....	9	<b>S</b>	
Operating modes.....	12	Sampling Rate .....	76
Absolute positioning mode.....	18	Save Configuration to Drive/Read Configuration from Drive .....	10
Analog mode.....	34	Save to Drive .....	16
Analog Positioning mode .....	36	Scope mode.....	74
Clock Direction mode.....	31	Screenshot.....	76
Flag positioning mode.....	27	Search Controller.....	59
Joystick mode .....	34	Send State Byte Automatically Upon End Of Record.....	41
Relative positioning mode.....	18		
Speed mode.....	24		

---

Signal curves		Outputs.....	56
Clock Direction mode.....	33	Scope .....	74
Flag positioning mode.....	30	State .....	12
Relative/Absolute Position Mode.....	23	Statusdisplay .....	60
Speed mode.....	26	Target Current.....	75
Speed .....	45	Target position .....	74
Speed mode .....	24	Target speed.....	20
Start / Stop.....	76	Temperature .....	75
Start Travel Profile.....	76	Test Record .....	16
State .....	16, 55, 57, 60	Time constant .....	51
Statusdisplay .....	60	Timeout .....	58
Step mode .....	40	Tolerance Width.....	47
Stopping a record .....	16	Torque mode.....	38
Swing Out Time .....	47	Travel profiles .....	14, 17
System requirements.....	6	Trigger on.....	28
<b>T</b>		<b>U</b>	
Tabs.....	10	Update .....	9
Brake.....	43	User defined inputs .....	54
CL Parameter.....	62	User defined outputs.....	56
Communication .....	58	<b>V</b>	
Display Properties.....	43, 45	V Maximum .....	29
Error correction .....	46	Velocity loop.....	63
Expert.....	77	Voltage .....	76
Inputs .....	49	Voltage limit .....	49
Motor settings .....	39, 43		