
When adjusting the air gap, pay attention that parallelism and axial run-out tolerances must be added to the rated air gap. Mounting or demounting of the armature element is permitted only in energized condition to avoid overexpansion of the diapgragm spring at the armature element.



PERMANENT-MAGNET	BRAKE			
Static Holding Torque		Nm	0.4	
Backlash		0	n.a.	
Rated Power		W	8	
Operating Voltage	+6%-10%	V DC	24	
Release Voltage	max.	V DC	n.a.	
Re-Engage Voltage	min.	V DC	n.a.	
Duty Cycle	max.	%	100	
Resistance	±7%	Ω	72.0	
Inductance (brake closed)	±20%	Н	0.4	
Switch-Off Time		ms	10	
Switch-On Time		ms	2	
Max. Axial Force		N	n.a.	
Max. Radial Force (shaft m	iddle)	N	n.a.	
Max. Speed		rpm	1000	0
Moment of Inertia		kg m²	1.3	x10 ⁻⁶
Ambient Temperature	°C	-40	.+120	
Max. Ambient Humidity (r	non condensing)	%	85	
Max. Altitude above sea	m	2000)	
Insulation Class		·	F	
Insulation Resistance		МΩ	500	

Dielectric Strength

Protection Class

V AC 600

IP00

BRAKE SPECIFICATION

run in of the brake

NOTICE rated braking torque is only reached after running-in of the brake. As standard, brakes are brought to rated braking torque after installation by initial running-in. The initial running-in has already taken place at Nanotec. In this case, only an adjustment run with reduced circuits is required.

Slip time / s	2
Idle time / s	0.5
Speed / rpm	250
Circuits First running-in	50
Circuits Adjustment running-in	10

Notes on running-in process:

- -Energize the magnet
- -Rotate the drive/ motor with the speed
- -Do not energize the magnet
- -Let the brake slip according to the slip time
- -Energize the brake according to the idle time
- -Repeat the circuits according to the initial or adjustment run
- -Stop the drive/ motor
- -Check the torque
- -If the torque is not reached => repeat the process

If the brake is only used as a holding brake without dynamic load, the braking torque may drop. A new running-in (refreshment) must be done within the scope of maintenance.

"Maintenance running-in of the brake."

Maintenance running-in of the brake.

A maintenance interval of 4 weeks is recommended for normal industrial applications.

Slip time / s	0.5
Idle time / s	0.5
Speed / rpm	250
Circuits	5

	ISO 8015	SO 8015 ISO 1302		SO 1302 ISO		3 cK ISO 13715		Weight: ±10% 0.08			% 0.080 kg
						Date	Name				
					Drawn	31.01.2024	Reith_S		BRAKE-BKE-0.4-5.0		
					Reviewed	08.03.2024	Reith_S		-, -,-		
					Released	08.03.2024	Reith_S	20002258			
					Nanotec			20002256			A3 Page 1
REV	Rev. Text		Name	Date	PLUG & DRIVE		State: Released	Rev: 00	CONFIDENTIAL	€10	