

User Manual NanoLib

C#

Contents

1 This document and its conventions.....	4
2 Before you start.....	5
2.1 System and hardware requirements.....	5
2.2 Intended use and audience.....	5
2.3 Scope of delivery and warranty.....	5
3 The NanoLib architecture.....	6
3.1 User interface.....	6
3.2 NanoLib core.....	6
3.3 Communication libraries.....	6
4 Getting started.....	7
4.1 Prepare your system.....	7
4.2 Install the adapter driver for Windows.....	7
4.3 Connect your hardware.....	7
4.4 Load NanoLib.....	7
5 Starting the example project.....	8
6 Creating your own project.....	9
6.1 Prepare the Nuget repository.....	9
6.2 Create a new project.....	9
6.3 Build your project.....	9
7 Classes / functions reference.....	10
7.1 NanoLibAccessor.....	10
7.2 BusHardwareId.....	18
7.3 BusHardwareOptions.....	19
7.4 BusHwOptionsDefault.....	20
7.5 CanBaudRate.....	21
7.6 CanBus.....	21
7.7 CanOpenNmtService.....	21
7.8 CanOpenNmtState.....	21
7.9 Ixxat.....	21
7.10 IxxatAdapterBusNumber.....	22
7.11 DeviceHandle.....	22
7.12 DeviceId.....	22
7.13 ObjectDictionary.....	23
7.14 ObjectEntry.....	24
7.15 ObjectSubEntry.....	25
7.16 OdIndex.....	27
7.17 OdLibrary.....	28
7.18 Result classes.....	28
7.18.1 ResultVoid.....	29
7.18.2 ResultInt.....	29

7.18.3 ResultString.....	30
7.18.4 ResultArrayByte.....	30
7.18.5 ResultArrayInt.....	31
7.18.6 ResultBusHwIds.....	31
7.18.7 ResultDeviceId.....	32
7.18.8 ResultDeviceIds.....	32
7.18.9 ResultDeviceHandle.....	33
7.18.10 ResultConnectionState.....	33
7.18.11 ResultObjectDictionary.....	34
7.18.12 ResultObjectEntry.....	34
7.18.13 ResultObjectSubEntry.....	35
7.19 NlcCallback.....	36
7.20 NlcDataTransferCallback.....	36
7.21 NlcScanBusCallback.....	36
7.22 Serial.....	36
7.23 SerialBaudRate.....	36
7.24 SerialParity.....	37
7.25 NanotecException classes.....	37
7.25.1 AbortException.....	37
7.25.2 InvalidAddressException.....	38
7.25.3 ProtocolException.....	38
7.25.4 ResourceException.....	38
7.25.5 TimeoutException.....	38
8 Licenses.....	39
9 Imprint, contact, document history.....	40

1 This document and its conventions

This document describes the setup and use of the NanoLib library and contains a reference to all classes and functions for programming your own control software for Nanotec controllers. Before using the product, please note the font styles and typefaces that encode this document.

Underlined text marks a cross reference or hyperlink.

- Example 1: For exact instructions on the NanoLibAccessor, see Setup.
- Example 2: Install the lxxat driver and connect the CAN-to-USB adapter.

Italic text means: This is a *named object*, a *menu path / item*, a *tab / file name* or (if necessary) an expression in a *foreign language*.

- Example 1: Select *File > New > Blank Document*.
- Example 2: Open the *Tool* tab and select *Comment*.
- Example 3: In principle, this document distinguishes between:
 - User (= *Nutzer*; *usuario*; *utente* [pt.]; *utilisateur*; *utente* [it.] etc.).
 - Third-party user (= *Drittnutzer*; *tercero usuario*; *terceiro utente*; *tiers utilisateur*; *terzo utente* etc.).
 - End user (= *Endnutzer*; *usuario final*; *utente final*; *utilisateur final*; *utente finale* etc.).

Courier marks code blocks or programming commands.

- Example 1: Via Bash, call `sudo make install` to copy shared objects; then call `ldconfig`.
- Example 2: Use the following NanoLibAccessor function to change the logging level in NanoLib:

```
//  
        ***** C++ variant *****  
void setLoggingLevel(LogLevel level);
```

Bold text emphasizes individual words of **critical** importance. Alternatively, bracketed exclamation marks emphasize the critical(!) importance.

- Example 1: Protect yourself, others and your equipment. Follow our **general** safety notes that are generally applicable to **all** Nanotec products.
- Example 2: For your own protection, also follow our **specific** safety notes that apply to **this** specific product.

The verb *to co-click* means a click via secondary mouse key to open a context menu etc.

- Example 1: Co-click on the file, select *Rename*, and rename the file.
- Example 2: To check the properties, co-click on the file and select *Properties*.

2 Before you start

Before you start using NanoLib, you need to duly prepare your PC and inform yourself about the intended use and limitations of the library.

2.1 System and hardware requirements

NanoLib is executable only under 64-bit operating systems. It supports all Nanotec products with CANopen, Modbus RTU (including USB via virtual comport) and Modbus TCP.

NanoLib

v 0.7

64-bit OS requirements

- **Windows 10:** with Visual Studio; .NET Desktop Development

Fieldbus adapters / cables

- **CANopen:**
 - IXXAT USB-to-CAN V2
 - Nanotec ZK-USB-CAN-1
- **Modbus RTU:**
 - Nanotec ZK-USB-RS485-1 or equivalent USB-RS485 adapter
 - USB cable via virtual comport (VCP)
- **Modbus TCP:**
 - Ethernet cable according to product datasheet.

2.2 Intended use and audience

NanoLib is a program library for the operation of, and communication with, Nanotec controllers. NanoLib is intended to be used as a software component in a wide range of industrial applications where Nanotec controllers are installed.

The underlying operating system and the used hardware (PC) on which NanoLib is intended to run do not provide real-time capability. NanoLib can therefore not be used for applications that require synchronous multi-axis movement or are generally time-sensitive.

Under no circumstances may this Nanotec product be integrated as a safety component in a product or system. All products containing a component manufactured by Nanotec must, upon delivery to the end user, be provided with corresponding warning notices and instructions for safe use and safe operation. All warning notices provided by Nanotec must be passed on directly to the end user.

NanoLib solely and exclusively addresses duly skilled programmers in industrial application scenarios.

2.3 Scope of delivery and warranty

NanoLib comes as a *.zip folder from our download website for either EMEA / APAC or AMERICA. Duly store and unzip your download before setup. The NanoLib package contains:

- Interface classes as source code (API)
- Libraries that facilitate the communication via the fieldbus: *nanolibm_canopen.dll*, *nanolibm_modbus.dll*
- Core functions as libraries in binary format: *nanolib_csharp*
- Example project: *NanolibExample.sln* (Visual Studio project) and *NanolibExample* (main file)

For scope of warranty, please observe our terms and conditions for either EMEA / APAC or AMERICA. and strictly follow all license terms. **Note:** Nanotec is not liable for faulty or undue quality, handling, installation, operation, use, and maintenance of third-party equipment! For due safety, always follow valid OEM instructions.

3 The NanoLib architecture

NanoLib's modular software structure lets you organize freely customizable motor controller / fieldbus functions around a strictly preconfigured core. NanoLib contains the following modules:

User interface (API)	NanoLib core	Communication libraries
Interface and helper classes which	Libraries which	Fieldbus-specific libraries which
<ul style="list-style-type: none"> ■ grant access to your controller's OD (object dictionary) ■ are based on the NanoLib core functionalities. 	<ul style="list-style-type: none"> ■ implement the API functionality ■ interact with bus libraries. 	<ul style="list-style-type: none"> ■ serve as interface between NanoLib core and bus hardware.

3.1 User interface

The user interface consists of header interface files you can use to access the controller parameters. The user interface classes as described in the [Classes / functions reference](#) allow you to:

- Connect to the hardware (fieldbus adapter).
- Connect to the controller device.
- Access the OD of the device, to read/write the controller parameters.

3.2 NanoLib core

The NanoLib core comes with the library *nanolib_csharp.dll*. It implements the user interface functionality and is responsible for:

- Loading and managing the communication libraries.
- Providing the user interface functionalities in the [NanoLibAccessor](#). This communication entry point defines a set of operations you can execute on the NanoLib core and communication libraries.

3.3 Communication libraries

The communication libraries provided by NanoLib (*nanolibm_canopen.dll*, *nanolibm_modbus.dll*) serve as hardware abstraction layer between core and controller. The core loads these libraries at startup time from the designated project folder and uses them to establish communication with the controller via the corresponding protocol.

4 Getting started

Read and learn how to set up NanoLib for your operating system duly and connect your hardware as needed.

4.1 Prepare your system

Prepare the PC along your OS.

- In **Windows**: Install the latest Microsoft Visual Studio; .NET Desktop Development.

4.2 Install the adapter driver for Windows

Only after due driver installation, you may use the IXXAT USB-to-CAN V2 adapter. **Note:** All other supported adapters do not require a driver installation Refer to the product manual of USB drives, to find out how to activate the virtual comport (VCP).

1. Download and install the IXXAT VCI 4 driver for Windows from www.ixxat.com.
2. Connect the IXXAT USB-to-CAN V2 compact adapter to the PC via USB.
3. Via Device Manager: Check if both driver and adapter are duly installed/recognized.

4.3 Connect your hardware

To be able to run a NanoLib project, connect a compatible Nanotec controller to the PC using your adapter.

1. Connect your adapter to the controller using a suitable cable.
2. Connect the adapter to the PC according to the adapter data sheet.
3. Power on the controller using a suitable power supply.
4. If needed, change the communication settings of the Nanotec controller according to the instructions in the product manual.

4.4 Load NanoLib

For a first start with quick-and-easy basics, you may (but must not) use our example project.

1. According to your region and needs: Download NanoLib from our website for either [EMEA / APAC](#) or [AMERICA](#).
2. Unzip all files and folders from the NanoLib download package.

Select one option:

- **For quick-and easy basics:** See [Starting the example project](#).
- **For advanced customizing in Windows:** See [Creating your own project](#).

5 Starting the example project

With NanoLib duly loaded, the example project shows you through NanoLib usage with a Nanotec controller.

Note: For each step, comments in the provided example code explain the functions used. The example project *NanolibExample.sln* consists of:

- *Nanolib_Example.cs* (main file)
- *NanolibHelper.cs* (helper class for wrapping the NanoLib accessor)

In Windows with Visual Studio

1. Open the *NanolibExample.sln* file.
2. Open the *Nanolib_Example.cs*(main file).
3. Build the project (this will restore the nuget package).
4. Close and reopen Visual Studio.
5. Open the *Nanolib_Example.cs* again.
6. Compile and run the example code.

The example demonstrates the typical workflow for working with a controller:

1. Check the PC for connected hardware (adapters) and list them.
2. Establish connection to an adapter.
3. Scan the bus for connected controller devices.
4. Connect to a device.
5. Read/write from/to the object dictionary of the controller (examples provided in the code).
6. Close the connection to the device.
7. Close the connection to the adapter.

6 Creating your own project

Create, compile and run your own Windows project to use NanoLib.

6.1 Prepare the Nuget repository

1. Unpack all files and folders of the "nanolib_csharp_win_###.zip" file.
2. Create a folder for your local repository - Example: C:\NugetRepo.
3. Copy the *Nanolib.####.nupkg* from the unpacked zip NanoLib file in your local repository folder.
4. Add the local repository to *Visual Studio Tools->NuGet Package Manager -> Package Sources -> Add -> Add your directory*

6.2 Create a new project

1. Open Visual Studio, on the welcome screen click on *Create new project*.
2. Now choose the type of the project. Choose *Console App (.NET Framework) - C#* and click *next*.
3. Give the project a name (e.g. "NanolibTest") and set its location. Select Framework: .NET Framework 4.7.2
4. Click on *Create*.
5. Add *Nanolib Nuget Package* by right-clicking on your project -> *Manage Nuget Packages... -> Browse -> Nanolib -> Choose the latest version and click Install*.
Tip: If you cannot see the Nanolib Package your "package source" might be not selected.
6. Set the Target Platform to x64: Right Click on your project -> *Properties -> Build -> Platform target: x64*.

6.3 Build your project

Build your NanoLib project in MS Visual Studio.

1. Open the main ("Program.cs" in this example) and replace the text with the following code:

```
class Program
{
    static void Main(string[] args)
    {
        nlc.NanoLibAccessor accessor = nlc.Nanolib.getNanoLibAccessor();
    }
}
```

2. Go to the menu *Build* and choose *Build solution*.
→ In the compile output window, there should be no error:

```
===== Build: 1 succeeded, 0 failed, 0 up-to-date, 0 skipped =====
```

7 Classes / functions reference

Find here a list of the classes of NanoLib's User Interface and their member functions. The typical description of a function includes a short introduction, the function definition and a parameter / return list:

ExampleFunction ()

Tells you briefly what the function does.

```
public BusHardwareId(string busHardware_, string protocol_, string
    hardwareSpecifier_, string name_)
```

Parameters	<i>param_a</i>	Additional comment if needed.
	<i>param_b</i>	
Returns	<i>ResultVoid</i>	Additional comment if needed.

7.1 NanoLibAccessor

Interface class used as entry point to the NanoLib. A typical workflow looks like this:

1. Start by scanning for hardware with `NanoLibAccessor.listAvailableBusHardware ()`.
2. Set the communication settings with `BusHardwareOptions ()`.
3. Open the hardware connection with `NanoLibAccessor.openBusHardwareWithProtocol ()`.
4. Scan the bus for connected devices with `NanoLibAccessor.scanDevices ()`.
5. Add a device with `NanoLibAccessor.addDevice ()`.
6. Connect to the device with `NanoLibAccessor.connectDevice ()`.
7. After finishing the operation, disconnect the device with `NanoLibAccessor.disconnectDevice ()`.
8. Remove the device with `NanoLibAccessor.removeDevice ()`.
9. Close the hardware connection with `NanoLibAccessor.closeBusHardware ()`.
10. Familiarize yourself with the class's following public member functions:

listAvailableBusHardware ()

Use this function to list the available fieldbus hardware.

```
virtual ResultBusHwIds listAvailableBusHardware()
```

Returns	<i>ResultBusHwIds</i>	Delivers a <u>fieldbus ID array</u> .
---------	-----------------------	---------------------------------------

openBusHardwareWithProtocol ()

Use this function to establish connection with a bus hardware.

```
virtual ResultVoid openBusHardwareWithProtocol(BusHardwareId busHwId,
    BusHardwareOptions busHwOpt)
```

Parameters	<i>busHwId</i>	Specifies the <u>fieldbus</u> to open.
	<i>busHwOpt</i>	Specifies <u>fieldbus opening options</u> .
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

getProtocolSpecificAccessor ()

Use this function to get the protocol-specific accessor object.

```
virtual ResultVoid getProtocolSpecificAccessor(BusHardwareId busHwId)
```

Parameters	<i>busHwId</i>	Specifies the <u>fieldbus</u> to get the accessor for.
------------	----------------	--

Returns *ResultVoid* Confirms the execution of a void function.

setBusState ()

Use this function to set the bus-protocol-specific state.

```
virtual ResultVoid setBusState(BusHardwareId busHwId, string state)
```

Parameters	<i>busHwId</i>	Specifies the <u>fieldbus</u> to open.
	<i>state</i>	Assigns a bus-specific state as a string value.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

scanDevices ()

Use this function to scan for devices in the network.

```
virtual ResultDeviceIds scanDevices(BusHardwareId busHwId, NlcScanBusCallback callback)
```

Parameters	<i>busHwId</i>	Specifies the <u>fieldbus</u> to scan.
	<i>callback</i>	<u>NlcScanBusCallback</u> progress tracer.
Returns	<i>ResultDeviceIds</i>	Delivers a <u>device ID</u> array.

addDevice ()

Use this function to add a bus device described by *deviceId* to the NanoLib internal device list and return *deviceHandle* for it.

```
virtual ResultDeviceHandle addDevice(DeviceId deviceId)
```

Parameters	<i>deviceId</i>	Specifies the device to add to the list.
Returns	<i>ResultDeviceHandle</i>	Delivers a <u>device handle</u> .

connectDevice ()

Use this function to establish connection with a device using *deviceHandle*.

```
virtual ResultVoid connectDevice( Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should connect to.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

getDeviceName ()

Use this function to get the device name using *deviceHandle*.

```
virtual ResultString getDeviceName( Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the name for.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

getDeviceProductCode ()

Use this function to get the device product code using *deviceHandle*.

```
virtual ResultInt getDeviceProductCode( Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the product code for.
Returns	<i>ResultInt</i>	Delivers the product code as an <u>integer</u> .

getDeviceVendorId ()

Use this function to get the device vendor ID using *deviceHandle*.

```
virtual ResultInt getDeviceVendorId( Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the vendor id for.
Returns	<i>ResultInt</i>	Delivers the product code as an <u>integer</u> .

getDeviceId ()

Use this function to get the device ID of a specific device from the NanoLib internal list.

```
virtual ResultDeviceId getDeviceId( Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the device ID for.
Returns	<i>ResultDeviceId</i>	Delivers a <u>device ID</u> .

getDeviceIds ()

Use this function to get the device ID of all devices from the NanoLib internal list.

```
virtual ResultDeviceIds getDeviceIds()
```

Returns	<i>ResultDeviceIds</i>	Delivers a <u>device ID list</u> .
---------	------------------------	------------------------------------

getDeviceUid ()

Use this function to get the device ID of a specific device from the NanoLib internal list.

```
virtual ResultDeviceId getDeviceUid( Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the device ID for.
Returns	<i>ResultDeviceId</i>	Delivers a <u>device ID</u> .

getDeviceSerialNumber ()

Use this function to get the serial of a device from the NanoLib internal list.

```
virtual ResultString getDeviceSerialNumber(Nlc.DeviceHandle deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the serial number for.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

getDeviceBootloaderBuildId ()

Use this function to get a bus device's bootloader build ID via device handle.

```
virtual ResultString getDeviceBootloaderBuildId( Nlc.DeviceHandle
  deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the bootloader build ID for.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

getDeviceFirmwareBuildId ()

Use this function to get a bus device's firmware build ID via device handle.

```
virtual ResultString getDeviceFirmwareBuildId( Nlc.DeviceHandle  deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the firmware build ID for.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

getDeviceHardwareVersion ()

Use this function to get a bus device's hardware version via device handle.

```
virtual ResultString getDeviceHardwareVersion( Nlc.DeviceHandle  deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the hardware version for.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

getDeviceState ()

Use this function to get the device-protocol-specific state.

```
virtual ResultString getDeviceState( Nlc.DeviceHandle  deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the state for.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

setDeviceState ()

Use this function to set the device-protocol-specific state.

```
virtual ResultVoid setDeviceState( Nlc.DeviceHandle  deviceHandle, string
  state)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should set the state for.
	<i>state</i>	Assigns a bus-specific state as a string value.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

getConnectionState ()

Use this function to get the connection state of a specific device using *deviceHandle*.

```
virtual ResultConnectionState getConnectionState( Nlc.DeviceHandle
  deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should set the state for.
Returns	<i>ResultConnectionState</i>	Delivers a <u>connection state</u> .

assignObjectDictionary ()

Use this function to assign an object dictionary to *deviceHandle*.

```
virtual ResultObjectDictionary assignObjectDictionary( Nlc.DeviceHandle
  deviceHandle, ObjectDictionary objectDictionary)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should assign the OD to.
	<i>objectDictionary</i>	
Returns	<i>ResultObjectDictionary</i>	Shows the <u>properties of an object dictionary</u> .

getAssignedObjectDictionary ()

Use this function to get the object dictionary assigned to a device using *deviceHandle*.

```
virtual ResultObjectDictionary getAssignedObjectDictionary( Nlc.DeviceHandle
  deviceHandle)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should get the assigned OD for.
Returns	<i>ResultObjectDictionary</i>	Shows the <u>properties of an object dictionary</u> .

objectDictionaryLibrary ()

This function returns a reference to the object dictionary library.

```
virtual OdLibrary objectDictionaryLibrary()
```

Returns	<i>OdLibrary&</i>	Shows which <u>object dictionary</u> is assigned to what library.
---------	-----------------------	---

setLoggingLevel ()

Use this function to set the needed logging level and limit the console output of the library.

```
virtual void setLoggingLevel(LogLevel level)
```

Parameters	<i>level</i>	The following levels are possible:
0 = <i>Off</i>	Switches off the logging entirely.	
1 = <i>Trace</i>	Lowest level, logs everything (expect huge logfiles).	
2 = <i>Debug</i>	Logs only debug information.	
3 = <i>Info</i>	Default level.	
4 = <i>Warn</i>	Message on recoverable problems.	
5 = <i>Error</i>	Highest level, only for messages followed very likely by a program exit.	

readNumber ()

Use this function to read a numeric value from the controller object dictionary.

```
virtual ResultInt readNumber( Nlc.DeviceHandle deviceHandle, Nlc.OdIndex
    odIndex)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should read from.
	<i>odIndex</i>	Specifies the <u>(sub-) index</u> to read from.
Returns	<i>ResultInt</i>	Delivers an <u>uninterpreted numeric value</u> (can be signed, unsigned, fix16.16 bit values).

readNumberArray ()

Use this function to read numeric arrays from the object dictionary.

```
virtual ResultArrayInt readNumberArray( Nlc.DeviceHandle deviceHandle, ushort
    index)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should read from.
	<i>index</i>	Array object index..
Returns	<i>ResultArrayInt</i>	Delivers an <u>array of integers</u> .

readBytes ()

Use this function to read arbitrary bytes (domain object data) from the object dictionary.

```
virtual ResultArrayByte readBytes( Nlc.DeviceHandle deviceHandle,
    Nlc.OdIndex odIndex)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should read from.
	<i>odIndex</i>	Specifies the <u>(sub-) index</u> to read from.
Returns	<i>ResultArrayByte</i>	Delivers an <u>array of bytes</u> .

readString ()

Use this function to read strings from the object directory.

```
virtual ResultString readString( Nlc.DeviceHandle deviceHandle, Nlc.OdIndex
    odIndex)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should read from.
	<i>odIndex</i>	Specifies the <u>(sub-) index</u> to read from.
Returns	<i>ResultString</i>	Delivers a device name as a <u>string</u> .

writeNumber ()

Use this function to write numeric values to the object directory.

```
virtual ResultVoid writeNumber( Nlc.DeviceHandle deviceHandle, long value,
    Nlc.OdIndex odIndex, uint bitLength)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should write to.
	<i>value</i>	The uninterpreted value (can be signed, unsigned, fix16.16).
	<i>odIndex</i>	Specifies the <u>(sub-) index</u> to read from.
	<i>bitLength</i>	Length in bit.

Returns *ResultVoid* Confirms the execution of a void function.

writeBytes ()

Use this function to write arbitrary bytes (domain object data) to the object directory.

```
virtual ResultVoid writeBytes( Nlc.DeviceHandle deviceHandle, ByteVector
data, Nlc.OdIndex odIndex)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should write to.
	<i>data</i>	Byte vector / array.
	<i>odIndex</i>	Specifies the <u>(sub-) index</u> to read from.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

firmwareUpload ()

Use this function to update your controller firmware.

```
virtual ResultVoid firmwareUpload( Nlc.DeviceHandle deviceHandle, ByteVector
fwData, Nlc.DataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should update.
	<i>fwData</i>	Array containing firmware data.
	<i>Nlc.DataTransferCallback</i>	A <u>data progress</u> tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

firmwareUploadFromFile ()

Use this function to update your controller firmware by uploading the firmware file.

```
virtual ResultVoid firmwareUploadFromFile( Nlc.DeviceHandle deviceHandle,
string absoluteFilePath, Nlc.DataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should update.
	<i>absoluteFilePath</i>	Path to file containing firmware data (string).
	<i>Nlc.DataTransferCallback</i>	A <u>data progress</u> tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

bootloaderUpload ()

Use this function to update your controller bootloader.

```
virtual ResultVoid bootloaderUpload( Nlc.DeviceHandle deviceHandle,
ByteVector btData, Nlc.DataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should update.
	<i>btData</i>	Array containing bootloader data.
	<i>Nlc.DataTransferCallback</i>	A <u>data progress</u> tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a <u>void function</u> .

bootloaderUploadFromFile ()

Use this function to update your controller bootloader by uploading the bootloader file.

```
virtual ResultVoid bootloaderUploadFromFile( Nlc.DeviceHandle deviceHandle,
string bootloaderAbsolutePath, Nlc.DataTransferCallback callback)
```


Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should update.
	<i>bootloaderAbsolutePath</i>	Path to file containing bootloader data (string)
	<i>NlcDataTransferCallback</i>	A data progress tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a void function .

bootloaderFirmwareUpload ()

Use this function to update your controller bootloader and firmware.

```
virtual ResultVoid bootloaderFirmwareUploadFromFile( Nlc.DeviceHandle
deviceHandle, string bootloaderAbsolutePath, string absoluteFilePath,
NlcDataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should update.
	<i>btData</i>	Array containing bootloader data.
	<i>fwData</i>	Array containing firmware data.
	<i>NlcDataTransferCallback</i>	A data progress tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a void function .

bootloaderFirmwareUploadFromFile ()

Use this function to update your controller bootloader and firmware by uploading the files.

```
virtual ResultVoid bootloaderFirmwareUploadFromFile( Nlc.DeviceHandle
deviceHandle, string bootloaderAbsolutePath, string absoluteFilePath,
NlcDataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should update.
	<i>bootloaderAbsolutePath</i>	Path to file containing bootloader data (string).
	<i>absoluteFilePath</i>	Path to file containing firmware data (uint8_t).
	<i>NlcDataTransferCallback</i>	A data progress tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a void function .

nanojUpload ()

Use this public function to upload the NanoJ program to your controller.

```
virtual ResultVoid nanojUpload( Nlc.DeviceHandle deviceHandle, ByteVector
vmmData, NlcDataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should upload to.
	<i>vmmData</i>	Array containing NanoJ data.
	<i>NlcDataTransferCallback</i>	A data progress tracer.
Returns	<i>ResultVoid</i>	Confirms the execution of a void function .

nanojUploadFromFile ()

Use this public function to upload the NanoJ program to your controller by uploading the file.

```
virtual ResultVoid nanojUploadFromFile( Nlc.DeviceHandle deviceHandle, string
absoluteFilePath, NlcDataTransferCallback callback)
```

Parameters	<i>deviceHandle</i>	Specifies which bus device NanoLib should upload to.
	<i>absoluteFilePath</i>	Path to file containing NanoJ data (string).
	<i>NlcDataTransferCallback</i>	A data progress tracer.

Returns *ResultVoid* Confirms the execution of a void function.

disconnectDevice ()

Use this function to disconnect your device.

```
virtual ResultVoid disconnectDevice( Nlc.DeviceHandle deviceHandle)
```

Parameters *deviceHandle* Specifies which bus device NanoLib should disconnect from.

Returns *ResultVoid* Confirms the execution of a void function.

removeDevice ()

Use this function to remove your device from the internal NanoLib device list.

```
virtual ResultVoid removeDevice( Nlc.DeviceHandle deviceHandle)
```

Parameters *deviceHandle* Specifies which bus device NanoLib should remove from the list.

Returns *ResultVoid* Confirms the execution of a void function.

closeBusHardware ()

Use this function to close the connection to your fieldbus hardware.

```
virtual ResultVoid closeBusHardware(BusHardwareId busHwId)
```

Parameters *busHwId* Specifies the fieldbus to close the connection to.

Returns *ResultVoid* Confirms the execution of a void function.

7.2 BusHardwareId

Use this class to identify a bus hardware one-to-one or to distinguish different bus hardware from each other. This class, without setter functions to be immutable from creation on, also holds information on:

- Hardware (= adapter name, network adapter etc.)
- Protocol to use (= Modbus TCP, CANopen etc.)
- Bus hardware specifier (= serial port name, MAC address etc.)
- Friendly name

BusHardwareId ()

Creates a new bus hardware ID object.

```
BusHardwareId(string busHardware_, string protocol_,  
string hardwareSpecifier_,  
string extraHardwareSpecifier_, string name_)
```

Parameters	<i>busHardware_</i>	Hardware type (= ZK-USB-CAN-1 etc.)
	<i>protocol_</i>	Bus communication protocol (= CANopen etc.)
	<i>hardwareSpecifier_</i>	The specifier of a hardware (= COM3 etc.)
	<i>extraHardwareSpecifier</i>	The extra specifier of the hardware (USB location info for example)
	<i>name_</i>	A friendly name (= <i>AdapterName (Port)</i> etc.)

equals ()

Compares a new bus hardware ID to existing ones.

```
bool equals(BusHardwareId other)
```

Parameters	<i>other</i>	Another object of the same class.
Returns	<i>true</i>	If both are equal in all values.
	<i>false</i>	If the values differ.

getBusHardware ()

Reads out the bus hardware string.

```
string getBusHardware()
```

Returns *string*

getHardwareSpecifier ()

Reads out the bus hardware's specifier string (= MAC address etc.).

```
string getHardwareSpecifier()
```

Returns *string*

getName ()

Reads out the bus hardware's friendly name.

```
string getName()
```

Returns *string*

getProtocol ()

Reads out the bus protocol string.

```
string getProtocol ()
```

Returns *string*

toString ()

Reads out the bus hardware ID as a string.

```
string toString ()
```

Returns *string*

7.3 BusHardwareOptions

Find in this class, in a key-value list of strings, all options needed to open a bus hardware.

BusHardwareOptions () [1/2]

Creates a new bus hardware option object.

```
BusHardwareOptions()
```

Use the function `void addOption(string key, string value)` to add key-value pairs.

BusHardwareOptions () [2/2]

Creates a new bus hardware options object with the key-value map already in place.

```
BusHardwareOptions(String_String_Map options)
```

Parameters	<i>options</i>	A map with options for the bus hardware to operate.
------------	----------------	---

addOption ()

Creates additional keys and values.

```
void addOption(string key, string value)
```

Parameters	<i>key</i>	Example: BAUD_RATE_OPTIONS_NAME
	<i>value</i>	Example: BAUD_RATE_1000K

equals ()

Compares the BusHardwareOptions to existing ones.

```
bool equals(BusHardwareOptions other)
```

Parameters	<i>other</i>	Another object of the same class.
Returns	<i>true</i>	If the other object has all of the exact same options.
	<i>false</i>	If the other object has different keys or values.

getOptions ()

Reads out all added key-value pairs.

```
String_String_Map getOptions()
```

Returns	<i>string map</i>
---------	-------------------

toString ()

Reads out all keys / values as a string.

```
string toString()
```

Returns	<i>string</i>
---------	---------------

7.4 BusHwOptionsDefault

This default configuration options class has the following public attributes:

<code>const CanBus</code>	<code>canBus = CanBus ()</code>
<code>const Serial</code>	<code>serial = Serial ()</code>

7.5 CanBaudRate

Struct that contains CAN bus baudrates in the following public attributes:

string	BAUD_RATE_1000K = "1000k"
string	BAUD_RATE_800K = "800k"
string	BAUD_RATE_500K = "500k"
string	BAUD_RATE_250K = "250k"
string	BAUD_RATE_125K = "125k"
string	BAUD_RATE_100K = "100k"
string	BAUD_RATE_50K = "50k"
string	BAUD_RATE_20K = "20k"
string	BAUD_RATE_10K = "10k"
string	BAUD_RATE_5K = "5k"

7.6 CanBus

Default configuration options class with the following public attributes:

string	BAUD_RATE_OPTIONS_NAME = "can adapter baud rate"
const CanBaudRate	baudRate = <u>CanBaudRate</u> ()
const Ixxat	ixxat = <u>Ixxat</u> ()

7.7 CanOpenNmtService

For the NMT service, this struct contains the CANopen NMT states as string values in the following public attributes:

string	START = "START"
string	STOP = "STOP"
string	PRE_OPERATIONAL = "PRE_OPERATIONAL"
string	RESET = "RESET"
string	RESET_COMMUNICATION = "RESET_COMMUNICATION"

7.8 CanOpenNmtState

This struct contains the CANopen NMT states as string values in the following public attributes:

string	STOPPED = "STOPPED"
string	PRE_OPERATIONAL = "PRE_OPERATIONAL"
string	OPERATIONAL = "OPERATIONAL"
string	INITIALIZATION = "INITIALIZATION"
string	UNKNOWN = "UNKNOWN"

7.9 Ixxat

This struct holds all information for the IXXAT usb-to-can in the following public attributes:

string	ADAPTER_BUS_NUMBER_OPTIONS_NAME = "ixxat adapter bus number"
const IxxatAdapterBusNumber	adapterBusNumber = <u>IxxatAdapterBusNumber</u> ()

7.10 IxxatAdapterBusNumber

This struct holds the bus number for the IXXAT usb-to-can in the following public attributes:

string	BUS_NUMBER_0_DEFAULT = "0"
string	BUS_NUMBER_1 = "1"
string	BUS_NUMBER_2 = "2"
string	BUS_NUMBER_3 = "3"

7.11 DeviceHandle

This class represents a handle for controlling a device on a bus and has the following public member functions.

DeviceHandle ()

```
DeviceHandle(DeviceHandle deviceHandle)
```

Returns *ResultVoid*

7.12 DeviceId

Use this class (not immutable from creation on) to identify and distinguish devices on a bus:

- Hardware adapter identifier
- Device identifier
- Description

The meaning of device ID / description values depends on the bus. Thus, a CAN bus may use the integer ID.

DeviceId ()

Creates a new device ID object.

```
DeviceId(BusHardwareId busHardwareId_, uint deviceId_,  
string description_, const extraId_, string const extraStringId_)
```

Parameters	<i>busHardwareId_</i>	Identifier of the bus.
	<i>deviceId_</i>	An index; subject to the bus (= CANopen node ID etc.).
	<i>description_</i>	A description (maybe empty); subject to the bus.
	<i>extraId_</i>	An additional ID (may be empty), meaning is depending on the bus.
	<i>extraStringId_</i>	An additional String Id (may be empty), meaning is depending on the bus.

equals ()

Compares new to existing objects.

```
bool equals(DeviceId other)
```

Returns *boolean*

getBusHardwareId ()

Reads out the bus hardware ID.

```
BusHardwareId getBusHardwareId()
```

Returns *BusHardwareId*

getDescription ()

Reads out the device description (maybe unused).

```
string getDescription()
```

Returns *string*

getDeviceId ()

Reads out the device ID (maybe unused).

```
uint getDeviceId()
```

Returns *unsigned int*

toString ()

Reads out the object as a string.

```
string toString()
```

Returns *string*

getExtrald()

Get the extra ID of the device (may be unused).

```
string toString()
```

Returns *vector extrald_* A vector of the additional *extralds* (may be empty), meaning is depending on the bus.

getExtraStringId()

Get the extra string ID of the device (may be unused).

```
string etExtraStringId()
```

Returns *string* The additional *StringId* (may be empty), meaning is depending on the bus.

7.13 ObjectDictionary

This class represents an object dictionary of a controller and has the following public member functions:

getDeviceHandle

```
virtual ResultDeviceHandle getDeviceHandle()
```

Returns *ResultDeviceHandle*

getObject

```
virtual ResultObjectSubEntry getObject( Nlc.OdIndex odIndex)
```

Returns *ResultObjectSubEntry*

getObjectEntry

```
virtual ResultObjectEntry getObjectEntry(ushort index)
```

Returns *ResultObjectEntry*

readNumber

```
virtual ResultInt readNumber( Nlc.OdIndex odIndex)
```

Returns *ResultInt*

readNumberArray

```
virtual ResultArrayInt readNumberArray(ushort index)
```

Returns *ResultArrayInt*

readString

```
virtual ResultString readString( Nlc.OdIndex odIndex)
```

Returns *ResultString*

readBytes

```
virtual ResultArrayByte readBytes( Nlc.OdIndex odIndex)
```

Returns *ResultArrayByte*

writeNumber

```
virtual ResultVoid writeNumber( Nlc.OdIndex odIndex, long value)
```

Returns *ResultVoid*

writeBytes

```
virtual ResultVoid writeBytes( Nlc.OdIndex odIndex, ByteVector data)
```

Returns *ResultVoid*

7.14 ObjectEntry

This class represents an object entry of the object dictionary

The class has the following public member functions:

getName

Reads out the name of the object.

```
virtual string getName()
```


getPrivate

Checks if the object is private.

```
virtual bool getPrivate()
```

getIndex

Reads out the address of the object index.

```
virtual ushort getIndex()
```

getDataType

Reads out the data type of the object.

```
virtual ObjectEntryDataType getDataType()
```

getObjectCode

Reads out the object code (variable, array etc.).

```
virtual ObjectCode getObjectCode()
```

getObjectSaveable

Checks if the object is saveable.

```
virtual ObjectSaveable getObjectSaveable()
```

getMaxSubIndex

Reads out the number of subindices supported by this object.

```
virtual byte getMaxSubIndex()
```

getSubEntry

```
virtual ObjectSubEntry getSubEntry(byte subIndex)
```

See also [ObjectSubEntry](#).

7.15 ObjectSubEntry

Class representing an object sub-entry (subindex) of the object dictionary and has the following public member functions:

getName

Reads out the name of the subindex.

```
virtual string getName()
```

getSubIndex

Reads out the address of the subindex.

```
virtual byte getSubIndex()
```

getDataType

Reads out the data type of the subindex.

```
virtual ObjectEntryDataType getDataType()
```

getSdoAccess

Checks if the subindex is accessible via SDO.

```
virtual ObjectSdoAccessAttribute getSdoAccess()
```

getPdoAccess

Checks if the subindex is accessible/mappable via PDO.

```
virtual ObjectPdoAccessAttribute getPdoAccess()
```

getBitLength

Checks the subindex length.

```
virtual uint getBitLength()
```

getDefaultValueAsNumeric

Reads out the default value of the subindex for numeric data types.

```
virtual ResultInt getDefaultValueAsNumeric(string key)
```

getDefaultValueAsString

Reads out the default value of the subindex for string data types.

```
virtual ResultString getDefaultValueAsString(string key)
```

getDefaultValues

Reads out the default values of the subindex.

```
virtual String_String_Map getDefaultValues()
```

readNumber

Reads out the numeric actual value of the subindex.

```
virtual ResultInt readNumber()
```

readString

Reads out the string actual value of the subindex.

```
virtual ResultString readString()
```

readBytes

Reads out the actual value of the subindex in bytes.

```
virtual ResultArrayByte readBytes()
```

writeNumber

Writes a numeric value in the subindex.

```
virtual ResultVoid writeNumber(long value)
```

writeBytes

Writes a value in the subindex in bytes.

```
virtual ResultVoid writeBytes(ByteVector data)
```

7.16 OdIndex

Use this class, immutable from creation on, to wrap and locate object directory indices / sub-indices. A device's OD has up to 65535 (0xFFFF) rows and 255 (0xFF) columns; with gaps between the discontinuous rows. See the CANopen standard for further details.

OdIndex ()

Creates a new OdIndex object.

```
OdIndex(ushort index, byte subIndex)
```

Parameters	<i>index</i>	From 0 to 65535 (0xFFFF) incl.
	<i>subindex</i>	From 0 to 255 (0xFF) incl.

getIndex ()

Reads out the index (from 0x0000 to 0xFFFF).

```
ushort Index { get; }
```

getSubindex ()

Reads out the sub-index (from 0x00 to 0xFF)

```
byte SubIndex { get; }
```

toString ()

Reads out the (sub-) index as a string. The string default *0xIIII:0xSS* reads as follows:

- I = index from 0x0000 to 0xFFFF
- S = sub-index from 0x00 to 0xFF

```
std::string nlc::OdIndex::toString () const
```

```
string ToString()
```

Returns	<i>0xIIII:0xSS</i>	Default string representation
---------	--------------------	-------------------------------

7.17 OdLibrary

This class represents an object dictionary library and has the following public member functions:

getObjectDictionaryCount

```
virtual uint getObjectDictionaryCount()
```

getObjectDictionary

```
virtual ResultObjectDictionary getObjectDictionary(uint odIndex)
```

addObjectDictionaryFromFile

```
virtual ResultObjectDictionary addObjectDictionaryFromFile(string  
absoluteXmlFilePath)
```

addObjectDictionary

```
virtual ResultObjectDictionary addObjectDictionary(ByteVector odXmlData)
```

7.18 Result classes

Use the "optional" return values of these classes to check if a function call had success or not, and also locate the fail reasons. On a success, the *hasError ()* function returns *false*. Via *getResult ()*, you can read out the result value (depending on the result type, e.g., [ResultInt](#)). If your call fails, you can read out the reason via *getError ()*.

Protected attributes	<i>string</i>	errorString
	<i>NlcErrorCode</i>	errorCode
	<i>uint32_t</i>	exErrorCode

Also, this class has the following public member functions:

hasError ()

Reads out a function call's success.

```
bool hasError()
```

Returns	<i>true</i>	Means: call success. Use <i>getResult ()</i> to read out the value.
	<i>false</i>	Means: call failure. Use <i>getError ()</i> to read out the value.

getError ()

Reads out the reason if a function call fails.

```
bool getError()
```

Returns	<i>const string</i>
---------	---------------------

result ()

The following functions aid in defining the exact results:

```
Result(string errorString_)
```

```
Result(NlcErrorCode errCode, string errorString_)
```

```
Result(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
Result(NanotecException exception)
```

```
Result(Result result)
```

getErrorCode () const

```
NlcErrorCode getErrorCode()
```

getExErrorCode () const

```
uint32_t getExErrorCode () const
```

```
uint getExErrorCode()
```

7.18.1 ResultVoid

NanoLib sends you an instance of this class if the function returns void. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

ResultVoid ()

The following functions aid in defining the exact void result:

```
ResultVoid(string errorString_)
```

```
ResultVoid(NlcErrorCode errCode, string errorString_)
```

```
ResultVoid(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultVoid(NanotecException exception)
```

```
ResultVoid(Result result)
```

7.18.2 ResultInt

NanoLib sends you an instance of this class if the function returns an integer. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the integer result if a function call had success.

```
long getResult()
```

Returns *long*

ResultInt ()

The following functions aid in defining the exact integer result:

```
ResultInt(long result_)
```

```
ResultInt(string errorString_)
```

```
ResultInt(NlcErrorCode errCode, string errorString_)
```

```
ResultInt(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultInt(NanotecException exception)
```

```
ResultInt(Result result)
```

7.18.3 ResultString

NanoLib sends you an instance of this class if the function returns a string. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the string result if a function call had success.

```
string getResult()
```

Returns *const string*

ResultString ()

The following functions aid in defining the exact string result:

```
ResultString(string message, bool hasError_)
```

```
ResultString(NlcErrorCode errCode, string errorString_)
```

```
ResultString(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultString(NanotecException exception)
```

```
ResultString(Result result)
```

7.18.4 ResultArrayByte

NanoLib sends you an instance of this class if the function returns a byte array. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the byte vector if a function call had success.

```
ByteVector getResult()
```

Returns *const vector<uint8_t>*

ResultArrayByte ()

The following functions aid in defining the exact byte array result:

```
ResultArrayByte(ByteVector result_)
```

```
ResultArrayByte(string errorString_)
```

```
ResultArrayByte(NlcErrorCode errCode, string errorString_)
```

```
ResultArrayByte(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultArrayByte(NanotecException exception)
```

```
ResultArrayByte(Result result)
```

7.18.5 ResultArrayInt

NanoLib sends you an instance of this class if the function returns an integer array. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the integer vector if a function call had success.

```
IntVector getResult()
```

Returns `const vector<uint64_t>`

ResultArrayInt ()

The following functions aid in defining the exact integer array result:

```
ResultArrayInt(IntVector result_)
```

```
ResultArrayInt(string errorString_)
```

```
ResultArrayInt(NlcErrorCode errCode, string errorString_)
```

```
ResultArrayInt(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultArrayInt(NanotecException exception)
```

```
ResultArrayInt(Result result)
```

7.18.6 ResultBusHwIds

NanoLib sends you an instance of this class if the function returns a [bus-hardware-ID](#) array. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the bus-hardware-ID vector if a function call had success.

```
BusHWIdVector getResult()
```

Parameters *const vector<BusHardwareId>*

ResultBusHwIds ()

The following functions aid in defining the exact bus-hardware-ID-array result:

```
ResultBusHwIds(BusHWIdVector result_)
```

```
ResultBusHwIds(string errorString_)
```

```
ResultBusHwIds(NlcErrorCode errCode, string errorString_)
```

```
ResultBusHwIds(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultBusHwIds(NanotecException exception)
```

```
ResultBusHwIds(Result result)
```

7.18.7 ResultDeviceId

NanoLib sends you an instance of this class if the function returns a device ID. This class inherits the public functions and protected attributes from the result class and has the following public member functions:

getResult ()

Reads out the device ID vector if a function call had success.

```
DeviceId getResult()
```

Returns *const vector<DeviceId>*

ResultDeviceId ()

The following functions aid in defining the exact device ID result:

```
ResultDeviceId(DeviceId result_)
```

```
ResultDeviceId(string errorString_)
```

```
ResultDeviceId(NlcErrorCode errCode, string errorString_)
```

```
ResultDeviceId(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultDeviceId(Result result)
```

7.18.8 ResultDeviceIds

NanoLib sends you an instance of this class if the function returns a device ID array. This class inherits the public functions and protected attributes from the result class and has the following public member functions:

getResult ()

Returns the device ID vector if a function call had success.

```
DeviceIdVector getResult()
```

Returns *const vector<DeviceId>*

ResultDeviceIds ()

The following functions aid in defining the exact device-ID-array result:

```
ResultDeviceIds(DeviceIdVector result_)
```

```
ResultDeviceIds(string errorString_)
```

```
ResultDeviceIds(NlcErrorCode errCode, string errorString_)
```

```
ResultDeviceIds(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultDeviceIds(NanotecException exception)
```

```
ResultDeviceIds(Result result)
```

7.18.9 ResultDeviceHandle

NanoLib sends you an instance of this class if the function returns the monitoring outcome of a [device handle](#). This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the device handle if a function call had success.

```
Nlc.DeviceHandle getResult()
```

Returns *DeviceHandle*

ResultDeviceHandle ()

The following functions aid in defining the exact device handle result:

```
ResultDeviceHandle( Nlc.DeviceHandle result_)
```

```
ResultDeviceHandle(string errorString_)
```

```
ResultDeviceHandle(NlcErrorCode errCode, string errorString_)
```

```
ResultDeviceHandle(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultDeviceHandle(NanotecException exception)
```

```
ResultDeviceHandle(Result result)
```

7.18.10 ResultConnectionState

NanoLib sends you an instance of this class if the function returns a device-connection-state info. This class inherits the public functions and protected attributes from the [result class](#) and has the following public member functions:

getResult ()

Reads out the device handle if a function call had success.

```
DeviceConnectionStateInfo getResult()
```

Returns *DeviceHandle*

ResultConnectionState ()

The following functions aid in defining the exact connection state result:

```
ResultConnectionState(DeviceConnectionStateInfo result_)
```

```
ResultConnectionState(string errorString_)
```

```
ResultConnectionState(NlcErrorCode errCode, string errorString_)
```

```
ResultConnectionState(NlcErrorCode errCode, uint exErrCode, string  
errorString_)
```

```
ResultConnectionState(NanotecException exception)
```

```
ResultConnectionState(Result result)
```

7.18.11 ResultObjectDictionary

NanoLib sends you an instance of this class if the function returns the monitoring outcome of an object dictionary. This class inherits the public functions and protected attributes from the result class and has the following public member functions:

getResult ()

Reads out the device ID vector if a function call had success.

```
ObjectDictionary getResult()
```

Returns *const vector<Deviceld>*

ResultObjectDictionary ()

The following functions aid in defining the exact object dictionary result:

```
ResultObjectDictionary(ObjectDictionary result_)
```

```
ResultObjectDictionary(string errorString_)
```

```
ResultObjectDictionary(NlcErrorCode errCode, string errorString_)
```

```
ResultObjectDictionary(NlcErrorCode errCode, uint exErrCode, string  
errorString_)
```

```
ResultObjectDictionary(NanotecException exception)
```

```
ResultObjectDictionary(Result result)
```

7.18.12 ResultObjectEntry

NanoLib sends you an instance of this class if the function returns an object entry. This class inherits the public functions and protected attributes from the result class and has the following public member functions:

getResult ()

Returns the device ID vector if a function call had success.

```
ObjectEntry getResult()
```

Returns *const vector<DeviceId>*

ResultObjectEntry ()

The following functions aid in defining the exact object entry result:

```
ResultObjectEntry(ObjectEntry result_)
```

```
ResultObjectEntry(string errorString_)
```

```
ResultObjectEntry(NlcErrorCode errCode, string errorString_)
```

```
ResultObjectEntry(NlcErrorCode errCode, uint exErrCode, string errorString_)
```

```
ResultObjectEntry(NanotecException exception)
```

```
ResultObjectEntry(Result result)
```

7.18.13 ResultObjectSubEntry

NanoLib sends you an instance of this class if the function returns an object sub-entry. This class inherits the public functions and protected attributes from the result class and has the following public member functions:

getResult ()

Returns the device ID vector if a function call had success.

```
ObjectSubEntry getResult()
```

Returns *const vector<DeviceId>*

ResultObjectSubEntry ()

The following functions aid in defining the exact object sub-entry result:

```
ResultObjectSubEntry(ObjectSubEntry result_)
```

```
ResultObjectSubEntry(string errorString_)
```

```
ResultObjectSubEntry(NlcErrorCode errCode, string errorString_)
```

```
ResultObjectSubEntry(NlcErrorCode errCode, uint exErrCode, string  
errorString_)
```

```
ResultObjectSubEntry(NanotecException exception)
```

```
ResultObjectSubEntry(Result result)
```

7.19 NlcCallback

This parent class for callbacks has the following public member function:

callback ()

```
virtual ResultVoid callback()
```

Returns *ResultVoid*

7.20 NlcDataTransferCallback

Use this callback class for data transfers (firmware update, NanoJ upload etc.).

1. For a firmware upload: Define a class extending this one with a custom callback method implementation.
2. Use the new class's instances in *NanoLibAccessor.firmwareUpload ()* calls.

The class has the following public member function:

callback ()

```
virtual ResultVoid callback(DataTransferInfo info, int data)
```

Returns *ResultVoid*

7.21 NlcScanBusCallback

Use this callback class for bus scanning.

1. Define a class extending this one with a custom callback method implementation.
2. Use the instances of the new class in *NanoLibAccessor.scanDevices ()* calls.

The class has the following public member function.

callback ()

```
virtual ResultVoid callback(BusScanInfo info, DeviceIdVector devicesFound, int data)
```

Returns *ResultVoid*

7.22 Serial

Find here your serial communication options and the following public attributes:

:string	BAUD_RATE_OPTIONS_NAME = "serial baud rate"
SerialBaudRate	baudRate = SerialBaudRate ()
string	PARITY_OPTIONS_NAME = "serial parity"
SerialParity	parity = SerialParity ()

7.23 SerialBaudRate

Find here your serial communication baud rate and the following public attributes:

string	BAUD_RATE_7200 = "7200"
string	BAUD_RATE_9600 = "9600"
string	BAUD_RATE_14400 = "14400"

string	BAUD_RATE_19200 = "19200"
string	BAUD_RATE_38400 = "38400"
string	BAUD_RATE_56000 = "56000"
string	BAUD_RATE_57600 = "57600"
string	BAUD_RATE_115200 = "115200"
string	BAUD_RATE_128000 = "128000"
string	BAUD_RATE_256000 = "256000"

7.24 SerialParity

Find here your serial parity options and the following public attributes:

string	NONE = "none"
string	ODD = "odd"
string	EVEN = "even"
string	MARK = "mark"
string	SPACE = "space"

7.25 NanotecException classes

Check these classes if an operation went wrong due to time-outs or illogical / invalid addresses, arguments, protocols, resources etc. Class functions are:

```
NanotecException(string msg, NlcErrorCode errCode, uint exErrCode)
```

```
virtual string what()
```

```
NlcErrorCode getErrorCode()
```

```
uint getExErrCode()
```

7.25.1 AbortException

If an operation stalls, use this class to override the abort mechanism. The class offers the function

```
AbortException(string message, uint abortCode)
```

. From NanotecException, it also inherits the following public functions:

```
NanotecException(string msg, NlcErrorCode errCode, uint exErrCode)
```

```
virtual string what()
```

```
NlcErrorCode getErrorCode()
```

```
uint getExErrCode()
```

7.25.2 InvalidAddressException

If an object dictionary address is wrong, use this class to address the object correctly. The class offers the function `InvalidAddressException(string message)`. From `NanotecException`, it also inherits the following public functions:

```
NanotecException(string msg, NlcErrorCode errCode, uint exErrCode)
```

```
virtual string what()
```

```
NlcErrorCode getErrorCode()
```

```
uint getExErrorCode()
```

7.25.3 ProtocolException

Use this class on unexpected messages from the counterpart (= firmware etc.), or on unfulfilled preconditions, to meet the protocol. The class offers the function `ProtocolException(string message)`. From `NanotecException`, it also inherits the following public functions:

```
NanotecException(string msg, NlcErrorCode errCode, uint exErrCode)
```

```
virtual string what()
```

```
NlcErrorCode getErrorCode()
```

```
uint getExErrorCode()
```

7.25.4 ResourceException

Use this class to fix errors with required local resources, CAN adapters etc. The class offers the function `ResourceException(string message)`. From `NanotecException`, it also inherits the following public functions:

```
NanotecException(string msg, NlcErrorCode errCode, uint exErrCode)
```

```
virtual string what()
```

```
NlcErrorCode getErrorCode()
```

```
uint getExErrorCode()
```

7.25.5 TimeoutException

If a certain period exceeds, you can use this class to change or end the time-out. The class offers the function `TimeoutException(string message)`. From `NanotecException`, it also inherits the following public functions:

```
NanotecException(string msg, NlcErrorCode errCode, uint exErrCode)
```

```
virtual string what()
```

```
NlcErrorCode getErrorCode()
```

```
uint getExErrorCode()
```

8 Licenses

The NanoLib interface (*API*) and the example source code provided are licensed by Nanotec Electronic GmbH & Co. KG under the Creative Commons Attribution 3.0 Unported License (*CC BY*). The parts of the library provided in binary format (core and fieldbus communication libraries) are licensed under the Creative Commons Attribution-NoDerivatives 4.0 International License (*CC BY ND*).

Creative Commons

The following human-readable summary does not substitute the license(s) itself. You can find the respective license at creativecommons.org and linked below. You are free to:

CC BY 3.0

- **Share:** See right.
- **Adapt:** Remix, transform, and build upon the material for any purpose, even commercially.

CC BY-ND 4.0

- **Share:** Copy and redistribute the material in any medium or format.

The licensor cannot revoke the above freedoms as long as you obey the following license terms:

CC BY 3.0

- **Attribution:** You must give appropriate credit, provide a [link to the license](#), and indicate if changes were made. You may do so in any reasonable manner, but not in any way that suggests the licensor endorses you or your use.
- **No additional restrictions:** You may not apply legal terms or technological measures that legally restrict others from doing anything the license permits.

CC BY-ND 4.0

- **Attribution:** See left. **But:** Provide a [link to this other license](#).
- **No derivatives:** If you remix, transform, or build upon the material, you may not distribute the modified material.
- **No additional restrictions:** See left.

Note: You do not have to comply with the license for elements of the material in the public domain or where your use is permitted by an applicable exception or limitation.

Note: No warranties given. The license may not give you all of the permissions necessary for your intended use. For example, other rights such as publicity, privacy, or moral rights may limit how you use the material.

9 Imprint, contact, document history

© 2021 Nanotec Electronic GmbH & Co. KG. All rights reserved. No portion of this document to be reproduced without prior written consent. Specifications subject to change without notice. Errors, omissions, and modifications excepted. Original version.

Nanotec Electronic GmbH & Co. KG | Kapellenstraße 6 | 85622 Feldkirchen | Germany

Tel. +49 (0)89 900 686-0 | Fax +49 (0)89 900 686-50 | info@nanotec.de | www.nanotec.com

Document version	Date	Changes	Product release
1.0.0	06/2021	Edition	0.7.0